




CHOOSE THE RIGHT POWER ADAPTOR FOR YOUR LAPTOP:

- 1 Identify your laptop model on the following pages to determine the Targus power products compatible with your machine.
- 2 Determine where you want to use your power supply (At Home or in the Car or Plane).
- 3 If you are still unsure simply freecall Targus for expert advice on the best product for your needs.



NEED FURTHER HELP CHOOSING THE RIGHT POWER ADAPTOR & TIP FOR YOUR LAPTOP?

Our customer service team are now available late night Thursday & Friday as well as Saturday & Sunday to assist.

Simply Freecall **Australia** 1800 641 645
or **New Zealand** 0800 633 222

Power Adaptors	Universal*		Replacement AC	
Product Name	Universal 90 Watt Wall Power Adaptor	Universal 90 Watt Wall, Auto/Air Power Adaptor	Home/Office 75 Watt AC Laptop Power Adaptor	Home/Office 90 Watt AC Laptop Power Adaptor
Product Code	APA64AU	APM64AU	APA02AU	APA03AU
Voltage Output:	Universal* Output voltage set by tip	Universal* Output voltage set by tip	15 - 16 V	18.5 - 20 V
Ideal for	Home	Home, Car & Plane	Home	Home
Power Input	AC wall	AC wall DC auto DC air	AC wall	AC wall
Tips Included in Pack	102, 104, 201, 202, 203, 204, 205, 206, 207, 209 or L104, L105, L106, L107, L108, L109, L110, L111, L112	102, 104, 201, 202, 203, 204, 205, 206, 207, 209 or L104, L105, L106, L107, L108, L109, L110, L111, L112	M, N, P	N,P, R, S, T, U

* Please check the Targus website (www.targus.com.au) or call Targus on the numbers below for full compatibility on Universal Power Adaptors - alternatively check this chart.

Revised for products effective October 2009

If your laptop model is not listed on this chart or on the chart supplied with the product, please contact Targus on the numbers below.

WARNING: Damage can be caused by the use of incorrect power tips. Care must be taken to ensure the correct tip is selected for your computer (laptop or device) as Targus Australia Pty Limited will not accept responsibility for any consequential damage upon the use of the incorrect power tip. It is stressed damage can be caused by the use of incorrect power tips. Compatibility is determined by Targus and in no way suggests endorsement by laptop manufacturers. Warranty details for Targus power adaptors are outlined on the product packaging. Targus is a trademark of Targus and all other marks shown are the property of their respective owners.



AC wall



DC auto



DC air

Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - AP464AU	75W AC APA02AU	90W AC APA03AU	
90W AC/DC - AP464AU			

Manufacturer	Model Name	Series	Tip	Tip	Tip
Acer	AcerNote	367D, 367T, 390	206/L106	✗	P
		350, 355, 356, 370C, 374, 850C	206/L106	✗	U
	AcerNote Light	380, 350, 360, 370, 370C, 370P, 370PC, 372, 373, 373+, P100	206/L106	✗	U
	Anywhere	1100LX, 1120LX	206/L106	✗	P
	Aspire	3023, 3025, 3025WLMi, 3053WXMi, 3102NWLMI, 3104LMI, 3683WXM, 4220-200508, 4520-301G12, 4520-5A0508, 5023WLMi, 5043WLMi, 5044WLMi, 5100-3372, 5112WLMi, 5315, 5520G-301G12, 5520G-402G16, 5520G-502G16, 5570z, 5580-6432, 5600, 5601AWLMI, 5610 Series, 5610-2273, 5610-4537, 5610-4610, 5610-4648, 5612WLMi, 5633WLMi, 5672WLMi, 5710 Series, 7520G-0602G20, 9300WLMi, 9305WSMi, 9425WSMi, 9500, AS3054WXM, AS4315, AS4920, AS5102AWLMI, AS5103WLMi, AS5104WLMi, AS5105WLMi, AS5520, AS5702, AS5720, AS5920, AS9305WLMi	102/L107	✗	✗
		1362WLMi, 1363WLCi, 1522WLMi, 1524WLMi, 5670	206/L106	✗	✗
		1641WLMi, 1642, 1642WLMi, 1642XWLMi, 1683WLMi, 1691WLCi, 2012WLCi, 2012WLMi, 2025WLMi, 2920, 2930, 3002LC, 3002LMI, 3002WLC, 3003WLCi, 3003WLMi, 3004WLCi, 3005WLCi, 3022WLMi, 3050-1594, 3100-1405, 3100-1458, 3508, 3613, 3614WLMi, 3618AWLMI, 3620, 3622WXCi, 3623, 3623NWXMI, 3623WLCi, 3623WLMi, 3623WXCi, 3623WXM, 3624, 3624WXCi, 3624WXM, 3634LMI, 3634WLMi, 3680-2022, 3690-2710, 3693WLMi, 3993WLMi, 4315-2004, 4315-2904, 4520-5582, 4715-4053, 4935, 5002WLMi, 5003WLMi, 5024, 5050-4570, 5050-5430, 5050-5954, 5100, 5100-3357, 5100-3577, 5100-3583, 5100-3825, 5100-3949, 5100-3959, 5100-5033, 5100-5328, 5100-5840, 5100-5873, 5101AWLMI, 5101WLMi, 5102AWLMI, 5102WLMi, 5104WLMi, 5105WLMi, 5315-2142, 5315-2808, 5512FWLM, 5512WLMi, 5513EWLM, 5514WLMi, 5514WXM, 5520-5281, 5520-5908, 5570-2067, 5570-2609, 5570-2758, 5570-2792, 5570-2935, 5570-4421, 5670WLMi, 5715, 5720-4230, 5720-4258, 5720-6113, 5735, 5735Z, 5920-6444, 5920-6574, 5920-6706, 6920-6141, 6920-6508, 6920-6621, 6920-6886, 6920G-583G25Bn, 6920G-583G32Bn, 6920G-6A3G25Bn, 6920G-6A4G25Mn, 6920G-814G32Bn, 6920G-834G32Bn, 6920G-934G32Bn, 6930-6809, 6930G-583G25Bn, 6930G-583G25Mn, 6930G-733G25Mn, 6935G-734G32Bn, 6935G-844G32Bn, 6935G-944G32Bn, 7520-5185, 7520-6A1G08Mi, 7520-7A1G08Mi, 7720-3A2G12Mi, 7720-5A2G16Mi, 7720-6381, 7720-6604, 7720-6844, 7720-6A2G25Mi, 7720G-302G25Mi, 7720G-302G25Mn, 7720G-302G32Hi, 7720G-5A2G16Mi, 7720Z-1A2G16Mi, 8920-6048, 8920G-6A3G25Bn, 8920G-6A4G32Bn, 8920G-834G32Bn, 8920G-934G50Bn, 8920G-934G64Bn, 8930G, 8930G-584G32Bn, 8930G-734G32Bn, 8930G-844G32Bn	207/L108	✗	✗
	Aspire Netbook	4330	207/L108	✗	✗
	Aspire One Netbook	751H, AOA110, AOA150, AOD150, AOD250, ZG5	102/L107	✗	✗
		One	207/L108	✗	✗
	Extensa	2900	102/L107	✗	✗
		515	104/L105	P	✗
		366D, 368D, 900, Ess3-391T	206/L106	✗	P
		355, 500, 501DX, 501T, 502D, 503DX, 505DX, 506DX, 600, 610CD, 610CDT	206/L106	✗	U
		2300, 3000, 4220-5963, 5220, 5220-2385, 5220-301G12Mi, 5230-571G16Mn, 5620-2A2G12Mi, 5620Z-4A1G12Mi, 5630-582G16Mn, 5630Z-322G16Mn, EX4220-2555, EX4420-5239, EX4420-5963, EX4620-4431, EX4620-4648, EX4620-6194, EX5420-5038, EX5620-4020, EX5620-4025, EX5620-4801, EX5620-6266, EX5620-6419	207/L108	✗	✗
	Ferrari	4005WLMi	206/L106	✗	✗
		3000LMI, 3400LMI, 4005LMI, 4006LMI, 4006WLMi	206/L106	✗	P
		1100-604G25Mn, 1100-704G25Mi, 1100-804G32Mn, 5005WLMi-FR	207/L108	✗	✗
Tablet	TMC104TCi, TMC110TCi, TMC110Ti	207/L108	✗	✗	
TravelMate	2413, 2434WLMi, 2600, 3280, 3290, 4200 Series, 4200-4091, 4200-4320, 4200-4493, 4200-4854, 4220, 4270, 4672WLMi, 5610, 5620, 5710 Series, 6410, 6410-6189, 6410-6248, 6460, 6460-6263, 6460-6752, 6492, 6592, 7720, 8200 Series, 8204WLMi, 8210, 8216WLHi	102/L107	✗	✗	
	512DX, 512T	104/L105	P	✗	



AC wall



DC auto



DC air

Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal	Replacement	
90W AC - AP64AU 90W AC/DC - AP164U	75W AC APA02AU	90W AC APA03AU

Manufacturer	Model Name	Series	Tip	Tip	Tip	
Acer	TravelMate	4202WLMi	206/L106	✗	✗	
		505DX, 506T, 507DX, 507T, 524TX, 524TXV	206/L106	✗	U	
		230, 2300, 2301WLCi, 2303WLCi, 2304WLCi, 230x, 230xc, 230xv, 230xv-PRO, 2310 Series, 2350 Series, 2400, 2410, 2413WLMi, 2418AWLMi, 2450, 2451WLCi, 2480, 2480-2153, 2480-2551, 2480-2705, 2480-2779, 290, 291, 3000 Series, 3002WTMI, 3004WTMI, 3010 Series, 3200 Series, 3210, 3220, 3230, 3270-6637, 380, 4000WLCi, 4001WLCi, 4001WLMi, 4002WLMi, 4050 Series, 4060, 4061, 4062, 4062WLMi, 4064, 4070, 4072, 4072WLCi, 4072WLMi, 4074, 4080, 4100, 4101WLMi, 4150 Series, 4222WLMi, 4270-6206, 4501WLMi, 4600 Series, 4603WLMi, 4604WLMi, 4720-6218, 4720-6220, 5004WLMi, 5270-6565, 5320-301G08Mi, 5320-301G12Mi, 5330-571G16Mi, 5530G-703G25Mn, 5602WLMi, 5720-2A3G16Mi, 5720-4A1G16Mi, 5720-4A2G16Mi, 5720-4A3G16Mi, 5720-5678, 5720-6337, 5720-6462, 5720-6722, 5730-6B2G16Mn, 5730-6B2G25Mn, 5730-6B4G25Mn, 5730-844G32Mn, 5730-944G32Mn, 5730G-843G25Mn, 5730G-844G32Bn, 6000, 6292-5B2G16Mi, 6292-603G32Mi, 6292-834G25Mi, 6292-834G32Mi, 6293-5B3G32Mn, 6293-6B2G25Mn, 6293-842G25Mn, 6492-812G25Mn, 6493-844G32Mn, 6592G-602G25Mn, 6592G-834G25Mn, 6593-842G25Mn, 6593G-842G25Mn, 6593G-944G32Mn, 7520-7A1G12Mi, 7530, 7530-602G25Mn, 7720G-602G25Mi, 7720G-702G50Mi, 7730-6B3G25Mn, 7730-843G25Mn, 7730G-944G32Mn, 8000, 8100 Series, 8100A, 8103WLMi, 8104, 8104WLMi, 8105, C110, C110CTI, C110TI, C300, TM220, TM230, TM260, TM270, TM279, TM280, TM350, TM360, TM370, TM380, TM520, TM530, TM610, TM620, TM630, TM660, TM730, TM740, TM800, TMC110, TMC113LCI	207/L108	✗	✗	
		4000	207/L108	✗	U	
Asus	Asus	A1 Series, F7 Series, M1 Series, M5, M8 Series, S1 Series, S200, S200N	102/L107	✗	✗	
		F7000, L1 Series, L7 Series, L8 Series, M5200N, M5N, S300N, S5, S5200N, S5N, S8 Series, T9 Series	102/L107	✗	T	
		A2L, A3 Series, A3000, A3000N, A3500N, A3Ac, A3F, A3Fc, A3Fp, A3H, A3Hf, A3N/L, A3Vc, A3Vm, A3Vp, A6 Series, A6F, A6G, A6K, A6Kt, A6L, A6M, A6Ne, A6R, A6Rp, A6T, A6Tc, A6U, A6V, A6Va, A6Vm, A7c, A7D, A7J, A7Jc, A7K, A7S, A7Sv, A7V, A8F, A8H, A8Ja, A8Jm, A8Jp, A8Js, A8M, A8SC-A1, A8SC-B1, A8SC-B2, A8SC-X3, A9Rp, AK6, B1 Series, B50A-A1, B50A-B1, B50A-B2, B50A-C2, F2F, F2Hf, F2J, F2Je, F3E-A1, F3E-B1, F3E-B2, F3E-B3, F3Jc, F3Jm, F3Jp, F3Ka, F3KA-X4, F3Sa, F3SC-A1, F3SC-B1, F3SV-A1, F3SV-B1, F3SV-B2, F3SV-B3, F3SV-B4, F3SV-C1, F50Gx, F5N, F5V-A1, F5VL-A2, F5VL-B1, F5VL-D1, F6A-A2, F6V-A1, F7KR, F80S-A1, F8P-B1W, F8P-C1B, F8P-C1W, F8P-X2B, F8Sn-A1, F8Sn-B1, F8Sn-C1, F8Sn-D1, F8Sp-X1, F8SV-A1, F8Va-B1, F8Va-C1, F9Dc-A1, F9Dc-B1, F9E-A1, F9S, F9Sg-A1, G1S-A1, G1S-B1, G1S-B2, G1Sn-A1, G1Sn-B1, G1S-X1, G1S-X3, G2K, G2K-A1, G2S, G2S-A1, G2S-A4, G2S-B1, G2S-B2, G2S-X3, L2B, L2E, L3000C, L3000TP, L3C, L3D, L4000E, L4000H, L4000L, L4000R, L4500R, L4E, L4H, L4R, L50Vn-A1, L50Vn-B1, L50Vn-C1, M2 Series, M2000C, M2400N, M2C, M2E, M2N, M2Ne Series, M3000N, M3N, M3Np, M50Sa-AK023C, M50Sa-X1, M50Sv-A1, M50Sv-B1, M50Vm-A1, M50Vm-B1, M50Vm-B2, M50Vm-B4, M51A-A1, M51A-B1, M51E-A1, M51E-B1, M51Sn-A1, M51Sn-B1, M51Sn-C1, M51Sn-X2, M51Sr, M51Vr, M5A Series, M5Ae, M6, M6A, M6C, M6Ce, M6N, M6Ne, M6Rf, M70SA-A1, M70SA-B1, M70SA-X2, M70Vm-A1, M70Vm-B1, M70Vm-C1, M70Vn-C1, M70Vn-C2, M7V, M7VP, M9J, M9V, N20A-A1, N50VC, N50Vn-A1B, N50Vn-B1B, N50Vn-C1S, N50Vn-C2S, N50Vn-C3S, N50VN-FP154C, N51Vf, N51Vg, N80Vn-A1, N80Vn-B1, PRO50, PRO50N, PRO55, R1E-B1, R1E-D1, R1F, R1F-A1, R1F-A2, S1000N, S1N, S5A, S6F Leather Collection, S6FM, U1E, U1F, U2E-A1B, U2E-B1B, U2E-B3B, U2E-X3, U3S-A1B, U3S-A1W, U5A, U6E, U6E-A1, U6E-X2, U6E-X3, U6S, U6V, V1S, V1S-A1, V1S-B1, V1V-A1, V2S, V2S-A1, V2S-B1, V6 Series, V6J, W1 Series, W1000Na, W1J00VC, W1Jc Carbon, W2Jc, W2P, W3 Series, W3A, W3J, W3N, W3V, W3Z, W5A, W5Ae, W5F, W6A, W6F, W6Fp, W7J, W7S-A1B, W7S-A1W, W7S-B1B, W7S-B2B, W7S-B2W, W7S-B3B, W7S-B3W, X59SR-A1, X71SL-A1, X71SL-B2, Z61Ae, Z71A, Z71V, Z71Vp, Z91N/L, Z93E	206/L106	✗	✗	
		A2C, A2Lp, A3E, A3G, A3N, A5E, A5Ec, A6000, A6J, A6JA, A6Jc, A6Je, A6Jm, A6KM, A8 Series, D1, F3F, F3J, F3JV, L1B, L2 Series, L3, L3H, L3S, L3Tp, L4, L4L, M5000, M5200, M6000, M6000C, M6000N, M6000R, M6R, M6V, M6Va, M7A, PRO30, PRO31F, PRO31J, PRO31P, PRO50SR, PRO50SR-AP301C, PRO50SR-AP327C, PRO77SV, S1A, S6F, V1J, V1JP, V6Z61A, W1000, W1-745, W1GC, W1N, W1NA, W1V, W2V, W7	206/L106	✗	P	
		Asus Netbook	N10J-A1, N10J-A2, N10Jc-A1	206/L106	✗	✗
		Grandio	F7400, L7000, L7000C, L7200, L7300	102/L107	✗	T
Lamborghini	VX1, VX2S-A1B, VX2S-A1Y, VX2S-A2B, VX2S-A2Y, VX2S-B1B, VX2S-B1Y, VX2S-B2B, VX2S-B2Y, VX3-A1B, VX3-A1Y	206/106	✗	✗		



AC wall



DC auto



DC air

Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - AP64AU	75W AC AP402AU	90W AC AP403AU	
90W AC/DC - AP164AU			

Manufacturer	Model Name	Series	Tip	Tip	Tip
BenQ	Joybook	527, 5000, 5100, 5120, 6000, 7000, 5100N, 5100U, A82, DH7000, R53, S52, S52E, S53, S53W, S72 Series	102/L107	✗	✗
		2100, 8000, 8100, A2400H, A32, A32E	206/L106	✗	P
		2100, 2100e, 3000, 3000v1, DH5000, DH5100, S100, V11, V12, V33, V37	207/L108	✗	T
Compaq	Armada	110, E500, E500S, E700, M300, M700, V300	102/L107	✗	T
	Business Tablet	TC4400	203/L111	✗	✗
	Evo	N110, N150, N200, N400c, N410c, N600c, N610c, N620c, N800c, N800v, N800w	102/L107	✗	T
		N1000v, N1015v, N1020c, N1020v	201/L107	✗	T
		N115, N160, N180	206/L106	✗	P
	Presario	2203AP, 2204AP, 2205AP, 2206AP, 2207AP, 2208AP, 2209AP, 2210AP, 2211AP, 2212AP, 2213AP, 2214AP, 2215AP, 2216AP, 2217AP, 2218AP, 2218RS, 2219AP, 2220AP, 2221AP, 2222AP, 2223AP, 2224AP, 2225AP, 2226AP, 2227AP, 2228AP, 2229AP, 2230AP, 2231AP, 2232AP, 2233AP, 2234AP, 2235AP, 2236AP, 2237AP, 2238AP, 2239AP, 2240AP, 2241AP, 2242AP, 2243AP, 2244AP, 2245AP, 2246AP, 2248AP, 2249AP, 2250AP, 2251AP, 2252AP, 2253AP, 2254AP, 2255AP, 2256AP, 2258AP, 2259AP, 2260AP, 2261AP, 2267AP, A936TU, B1801TU, B1900, B1959TU, B1973TU, B2800, B2801-TU, B3800, B3813AP, B3827AP, C302, C302TU, C310TU, C501TU, C502TU, C503TU, C504TU, C506TU, C551TU, C552TU, C553TU, C554TU, C555TU, C556TU, C557TU, C558TU, C559TU, C560TU, C561TU, C562TU, C563TU, C564TU, C565TU, C566TU, C567TU, C582TU, C700T, C710TU, C731TU, C763, C774TU, C7xxTU, DV6000T, F503AU, F551AU, F573AU, M2000, M2000Z, M2001AP, M2001xx, M2002AP, M2003AP, M2004AP, M2005AP, M2006AP, M2007AP, M2008AP, M2009AP, M2010AP, M2011AP, M2012AP, M2013AP, M2014AP, M2015AP, M2016AP, M2017AP, M2018AP, M2019AP, M2020AP, M2021AP, M2022AP, M2023AP, M2024AP, M2025AP, M2026AP, M2027AP, M2028AP, M2029AP, M2030AP, M2031AP, M2032AP, M2033AP, M2034AP, M2035AP, M2036AP, M2037AP, M2038AP, M2039AP, M2040AP, M2041AP, M2042AP, M2043AP, M2044AP, M2045AP, M2046AP, M2047AP, M2048AP, M2049AP, M2050AP, M2051AP, M2052AP, M2053AP, M2054AP, M2055AP, M2099xx, M2200, M2201AP, M2201TU, M2202AP, M2202TU, M2203AP, M2204AP, M2205AP, M2206AP, M2207AP, M2208AP, M2209AP, M2210AP, M2211AP, M2212AP, M2213AP, M2214AP, M2215AP, M2216AP, M2217AP, M2218AP, M2219AP, M2220AP, M2221AP, M2222AP, M2223AP, M2224AP, M2225AP, M2226AP, M2227AP, M2228AP, M2229AP, M2230AP, M2231AP, M2232AP, M2233AP, M2234AP, M2235AP, M2236AP, M2237AP, M2238AP, M2239AP, M2240AP, M2241AP, M2242AP, M2243AP, M2244AP, M2245AP, M2253AU, M2256AU, M2299xx MV IUR, M2340AP, M2401XT, N2000, V2000, V2001AP, V2002AP, V2003AP, V2004AP, V2005AP, V2006AP, V2007AP, V2008AP, V2009AP, V2010AP, V2011AP, V2012AP, V2013AP, V2014AP, V2015AP, V2016AP, V2017AP, V2018AP, V2019AP, V2020AP, V2021AP, V2022AP, V2024AP, V2025AP, V2026AP, V2027AP, V2028AP, V2029AP, V2030AP, V2031AP, V2032AP, V2033AP, V2034AP, V2035AP, V2036AP, V2042AP, V2100, V2157AP, V2300, V2300T, V2300Z, V2311AP, V2325AP, V2340AP, V2398xx MV IUR, V2399xx, V2399XX, V2400T, V2402AU, V2414TU, V2418AU, V2433AU, V2566AP, V2602XT, V2606CU, V2627AU, V2649TS, V3000, V3000T, V3000Z, V3020, V3021, V3118AU, V3200, V3200TU, V3201AU, V3201TU, V3202AU, V3202TU, V3203AU, V3203TU, V3204AU, V3204TU, V3205TU, V3206TU, V3207TU, V3208TU, V3211TU, V3218TU, V3219TU, V3230AU, V3239AU, V3239TU, V3240AU, V3243TU, V3244TU, V3250TU, V3255TU, V3256TU, V3307, V3329TU, V4000, V4000xx MV IUR, V4001AP, V4002AP, V4002xx MV IUR, V4003AP, V4003xx MV IUR, V4004AP, V4004xx MV IUR, V4005xx, V4100, V4101AP, V4102AP, V4103AP, V4104AP, V4105AP, V4106AP, V4107AP, V4108AP, V4109AP, V4110AP, V4111AP, V4112AP, V4113AP, V4114AP, V4115AP, V4116AP, V4117AP, V4118AP, V4119AP, V4120TU, V4121TU, V4122TU, V4201TU, V4202TU, V4209TU, V4214, V4229TU, V5000, V5000T, V5099xx, V5100, V5100Z, V5101AU, V5102TU, V5104AU, V5108CU, V5200, V6000, V6000T, V6000Z, V6001AU, V6002AU, V6003AU, V6107AP, V6107TU, V6109AU, V6150TU, V6201AU, V6204AU, V6301, V6502, X1401AP	102/L107	✗	✗
		2158AP	102/L107	✗	P
2866, 2867, 2868, 2869, 2870, 2871, 2887, 2888, 2890, 2891, 2892, 2893, 2894, 2895, 2896, 2897, 2898, 2899, 1500 Series, 2200, 2800, 2801, 2802, 2803, 2804, 2805, 2806, 2806AP, 2807, 2809, 2810, 2811, 2812, 2813, 2813AU, 2814, 2814AP, 2815, 2816, 2817, 2817AR, 2818, 2818AP, 2819, 2819AP, 2820, 2820AP, 2821, 2822, 2822AP, 2823, 2823AP, 2825, 2825AP, 2826, 2826TC, 2827, 2827AP, 2828, 2828AP, 2830, 2832, 2832AP, 2835, 2835AP, 2838, 2838AP, 2840, 2840TC, 2845, 2845AP, 2853, 2853AP, 2857, 2857AP, 2858, 2858AP, 2860, 2860AP, 2861, 2861AP, 2862, 2862AP, 2863, 2863AP, 2864, 2864AP, 2865, 2865AP, 2866AP, 2867AP, 2868AP, 2869AP, 2870AP, 2871AP, 2887AP, 2888AP, 2890AP, 2891AP, 2892AP, 2893AP, 2894AP, 2895AP, 2896AP, 2897AP, 2898AP, 2899AP, 2900, 2902, 2903, 2904, 2905, 2906, 2907, 2908, 300, 305, 900 Series, V1000, V1001AP, V1002AP, V1003AP, V1004AP, V1005AP, V1006AP, V1007AP, V1008AP, V1009AP, V1010AP, V1011AP, V1012AP, V1013AP, V1014AP, V1015AP, V1016AP, V1017AP, V1018AP, V1019AP, V1020AP, V1021AP, 1022AP,		102/L107	✗	T	



AC wall



DC auto



DC air

Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - AP68AU	75W AC - APA02AU	90W AC - APA03AU	
90W AC/DC - AP16AU			

Manufacturer	Model Name	Series	Tip	Tip	Tip
Compaq	Presario	V1023AP, V1024AP, V1025AP, V1026AP, V1027AP, V1028AP, V1029AP, V1030AP, V1031AP, V1032AP, V1033AP, V1034AP, V1035AP, V1036AP, V1037AP, V1038AP, V1039AP, V1040AP, V1041AP, V1042AP, V1043AP, V1044AP, V1045AP, V1046AP, V1047AP, V1048AP, V1049AP, V1050AP, V1051AP, V1052AP, V1053AP, V1054AP, V1055AP, V1056AP, V1057AP, V1058AP, V1059AP, V1060AP, V1061AP, V1062AP, V1063AP, V1064AP, V1065AP, V1066AP, V1067AP, V1068AP, V1069AP, V1070AP, V1071AP, V1072AP, V1073AP, V1074AP, V1075AP, V1101AP, 1102AP, V1103AP, V1104AP, V1105AP, V1106AP, V1107AP, V1108AP, V1109AP, V1110AP, V1111AP, V1112AP, V1113AP, X1000, X1010, X1012, X1012QV, X1021AP, X1022AP, X1023AP, X1026AP, X1027AP, X1028AP, X1029AP, X1030, X1031AP, X1032AP, X1033AP, X1034AP, X1035AP, X1036AP, X1037AP, X1038AP, X1040AP, X1041AP, X1042AP, X1043AP, X1044AP, X1045AP, X1046AP, 1047AP, X1048AP, X1049AP, X1050AP, X1051AP, X1052AP, X1053AP, X1054AP, X1055AP, X1056AP, X1057AP, X1058AP, X1060AP, X1061AP, X1062AP, X1063AP, X1064AP, X1065AP, X1066AP, X1067AP, X1068AP, X1069AP, X1070AP, X1071AP, X1072AP, X1073AP, X1074AP, X1075AP, X1076AP, X1077AP, X1078AP, X1079AP, X1080AP, X1081AP, X1082AP, X1083AP, X1084AP, X1085AP, X1086AP, X1087AP, X1088AP, X1089AP, X1090AP, X1091AP, X1092AP, X1093AP, X1094AP, X1095AP, X1096AP, X1097AP, X1098AP, X1099AP, X1200, X1201AP, X1202AP, X1203AP, X1204AP, X1205AP, X1206AP, X1207AP, X1208AP, X1209AP, X1210AP, X1211AP, X1212AP, X1213AP, X1214AP, X1215AP, X1216AP, X1217AP, X1218AP, X1219AP, X1220AP, X1221AP, X1222AP, X1223AP, X1224AP, X1225AP, X1227AP, X1228AP, X1229AP, X1230AP, X1231AP, X1232AP, X1233AP, X1234AP, X1236AP, X1237AP, X1238AP, X1239AP, X1240AP, X1241AP, X1242AP, X1300, X1301AP, X1302AP, X1303AP, X1304AP, X1305AP, X1306AP, X1307AP, X1308AP, X1309AP, X1310AP, X1311AP, X1312AP, X1313AP, X1314AP, X1315AP, X1316AP, X1317AP, X1318AP, X1319AP, X1320AP, X1321AP, X1322AP, X1324AP, X1325AP, X1326AP, X1327AP, 1328AP, X1330AP, X1360, X1460, X1480, X1480xx	102/L107	✗	T
		N1050V, V6002xx, V6500T, V6500Z, V6501AU, V6502AU, V6503AU, V6504AU, V6505AU, V6506AU, V6507AU, V6508AU	201/L107	✗	✗
		1501AP, 1503AP, 1504AP, 1506AP, 1507AP, 1508AP, 1509AP, 1510AP, 1510TC, 1511AP, 1512AP, 1514AP, 1520AP, 1522AP, 1525AP, 1528AP, 1531AP, 1532AP, 1535AP, 1536AP, 1538AP, 1540AP, 1545AP, 1550AP, 1555AP, 1565AP, 1570AP, 1572AP, 1575AP, 1580AP, 910AP, 920AP, 921AP, 923AP, 925AP, 927AP, 930AP, 935AP, 940AP, 943AP, 945AP, 950AP, 955AP	201/L107	✗	T
		6715b, B1200, B1201TU, CQ40-418AX, CQ40-419AU, CQ45-138TX, CQ60, CQ60-217TX, CQ60-302AU, CQ61-107TU, CQ61-115TU, CQ61-117TU	203/L111	✗	✗
	1110, 2100, 1010, 1020, 1030, 1060, 1065, 1070, 1075, 1080, 1115, 1120, 1200 series, 1200AP, 1200T-12XL, 1200TC, 1200TH, 1200-XL106, 1200-XL110, 1201, 1201AP, 1201S, 1202, 1203, 1205, 1206R, 1207, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1219, 1220, 1232, 1234, 1235, 1236, 1237, 1238, 1240, 1242, 1244, 1245, 1246, 1247, 1250, 1252, 1255, 1256, 1257, 1260, 1262, 1263, 1266, 1267, 1270, 1272, 1273, 1274, 1275, 1277, 1278, 1279, 12XL, 12XL300B, 12XL400, 12XL401, 12XL404, 12XL410, 12XL420, 12XL423, 12XL426, 12XL427, 12XL430, 12XL500, 12XL501, 12XL504, 12XL505, 12XL526, 12XL527, 1400, 1400T, 1450, 14XL, 14XL240, 1600, 1600 series, 1600i, 1600S, 1610, 1611, 1621, 1622, 1625, 1626, 1640, 1645, 1655, 1670, 1680, 1681, 1682, 1685, 1687, 1688, 1690, 1692, 1693, 1694, 16XL, 1700, 1700 series, 1700T, 1701, 1702, 1702AP, 1703, 1704, 1705, 1705AP, 1710, 1710T, 1711, 1712, 1713, 1714, 1715, 1716, 1717, 1720, 1721, 1722, 1723, 1723AP, 1724, 1724TC, 1725, 1725TC, 1726, 1726TC, 17XL, 17XL260, 17XL360, 1800, 1800t, 1800XL180, 18XL, 18XL280, 18XL580, 2100 series, 2100AP, 2100Z, 2101AP, 2102AP, 2103AP, 2104AP, 2105AP, 2106AP, 2107AP, 2108AP, 2109AP, 2110AP, 2111AP, 2112AP, 2113AP, 2114AP, 2115AP, 2116AP, 2117AP, 2120AP, 2123AP, 2124AP, 2125AP, 2130AP, 2133AP, 2135AP, 2140AP, 2143AP, 2145AP, 2150AP, 2153AP, 2154AP, 2155AP, 2156AP, 2157AP, 2175, 2500, 2500 series, 2500AP, 2501, 2505AP, 2510AP, 2515AP, 2517, 2519, 2520AP, 2525AP, 2529, 2530AP, 2535AP, 2538AP, 2540AP, 2543AP, 2545AP, 2550AP, 2555AP, 2560AP, 2565AP, 2567AP, 2568, 2568AP, 2570, 2573AP, 2585, 2590, 2594, 2596, 2597, 2598, 2700, 2700 series, 2700T, 2700TC, 2700xx, 2701, 2702, 2710, 2710TC, 2711, 2711AP, 2711TC, 2712, 2715, 2716, 2720, 3000, 3005, 3015, 3017, 3019, 3020, 3080, 700, 700 series, 701, 702, 703, 703AP, 704, 705, 706, 709, 710, 710TC, 711, 71110, 712, 713, 714, 715, 716, 717, 718, 719, 720, 721, 722, 723, 724, 725, 726, 727, 728, 729, 730, 731, 732, 733, 734, 735, 736, 737, 738, 739, 800, 800T, 801, 802, 803, 850	206/L106	✗	P	
	X1001	206/L107	✗	T	
	Prosignia	170, 190	102/L107	✗	T
150		206/L106	✗	P	
Tablet	TC-1000, TC-1100	102/L107	✗	T	
Dell	Inspiron	1521, 1721, 1150, 1318 (Intel Graphic card), 1318 (NVIDIA Graphic card), 1420 (Intel Graphic card), 1420 (NVIDIA Graphic card), 1501, 1520 (Intel Graphic card), 1520 (NVIDIA Graphic card), 1525, 1526, 1545, 1720 (Intel Graphic card), 1720 (NVIDIA Graphic card), 300M, 500M, 510M, 5160, 6000, 600M, 630M, 6400, 640m, 700M, 710M, 8500, 8600, 9200, 9300, 9400, E1405, E1505, E1705	202/L109	✗	✗



AC wall



DC auto



DC air

Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - AP464AU	75W AC APA02AU	90W AC APA03AU	
90W AC/DC - AP164AU			

Manufacturer	Model Name	Series	Tip	Tip	Tip
Dell	Inspiron	1200, 1300, 2200, 3000, 3200, 3500, 7000, B120, B130	206/L106	✗	P
		2500, 2600, 2650, 3700, 3800, 4000, 4150, 5000, 7500, 8000, 8100, 8200	✗/✗	✗	S
	Inspiron Netbook	Mini 12, Mini 9	207/L108	✗	T
	Latitude	XT, 131L, ATG D630, ATG E6400, D400, D410, D420, D430, D500, D505, D510, D520, D530, D531, D600, D610, D620 (Intel Graphic card), D620 (NVIDIA Graphic card), D630 (Intel Graphic card), D630 (NVIDIA Graphic card), D630(Intel Graphic Card), D630(NVidia Graphic Card), D800, D810, D820, D830, E4200, E4300, E5400, E5500, E6400, E6500, L100, X1, X300, XFR D630	202/L109	✗	✗
		110L	206/L108	✗	P
		C400, C410, C500, C510, C600, C610, C640, C800, C810, CP, CPi, CPt, CPx, CS/CSx, LM, X200	✗/✗	✗	S
	Precision	M20, M2300, M2400, M4300, M60, M65, M70	202/L109	✗	✗
	Studio	1535 (ATI Graphic card), 1535 (Intel Graphic card), 1536 (ATI Graphic card), 1536 (Intel Graphic card), 1537 (ATI Graphic card), 1537 (Intel Graphic card), 1735, 1737	202/L109	✗	✗
	Vostro	1000, 1400, 1500, 1700, 1310 (Intel Graphic card), 1310 (NVIDIA Graphic card), 1400 (Intel Graphic card), 1400 (NVIDIA Graphic card), 1500 (Intel Graphic card), 1500 (NVIDIA Graphic card), 1510 (Intel Graphic card), 1510 (NVIDIA Graphic card), 2510, A840, A860	202/L109	✗	✗
XPS	M1210, M1330 (Intel graphic card), M1330 (Nvidia graphic card), M1530	202/L109	✗	✗	
Fujitsu	Amilo M	M1420, M7400	206/L106	✗	P
	Amilo Pro	V2000D, V8010D	207/L108	✗	✗
	FMV-BIBLO	FLX2H, LOOX S80B, LOOX S80B/W, LOOX S80C, LOOX S80C/W, LOOX T50E, LOOX T50E/W, LOOX T50G/W, LOOX T50H, LOOX T50J, LOOX T50K, LOOX T55G, LOOX T70E, LOOX T70G, LOOX T70H, LOOX T70HN, LOOX T70J, LOOX T70JN, LOOX T70K/T, LOOX T93B, LOOX T93B/W, LOOX T93C, LOOX T93C/W, MG12B, MG12B/C, MG12B/M, MG12C, MG12C/M, MG12D, MG13D, MG17D/A, MG50E, MG50G, MG50H, MG50HN, MG50K, MG50K/T, MG55E, MG70E, MG70E/ST, MG70G, MG70G/ST, MG70H, MG70K/T, MG75E, MG75G, MG75H, MG75H/ST, MG75HN, MG75K, MR16B, NB14B, NB14B/R, NB15B, NB15B/S, NB15B/T, NB16B, NB16B/M, NB16C, NB16C/A, NB16C/R, NB16C/ST, NB16C/T, NB16C/V, NB16CA, NB16CR, NB18B, NB18C, NB18C/T, NB18D, NB18D/D, NB18D/F, NB18D/L, NB18D/V, NB19D, NB19D/D, NB50E, NB50G, NB50H, NB50HN, NB50J, NB50JN, NB50K, NB50K, NB53E, NB55E, NB55E/T, NB55G, NB55G/T, NB55H, NB55H/T, NB55J, NB55J/T, NB55K, NB55K/T, NB70E, NB70E/T, NB70G, NB70H/T, NB75G, NB75G/T, NB75H, NB75H/T, NB75HN, NB75HN/T, NB75J, NB75K/T, NB80J, NB80JN, NB80K, NB90J/T, NB90J/TS, NB90JN/T, NB90K/T, NB90K/TS, NB90KN/T, NH24C, NH24D, NH26C, NH28D, NH50E, NH70E, NH90E/T, NU, RS18D, RS18D/D, RS18D/ST, RS18D/T, RS50E/T, RS55E/T	✗/✗	N	✗
	LifeBook	A1010, A3110, Amilo L, C1010, C1020, C1110, C1211D, C1410, C2010, C2110, C2111, C2210, C2220, C2230, C2240, C2310, C2320, C2330, C2340, C3367, C6637, C6xx5, Cxxx7, E2010, E4010, E4010D, E6624, E6634, E6644, E6654, E6664, E66xx, E7010, E7110, E8010, E8010D, E8020, E8020D, E8110, E8210, N3510, N3511, N3520, N3530, N6110, N6210, N6220, S6130, S6410, S7010, S7010D, S7011, S7110, Stylistic ST4120, Stylistic ST4121, T4010, T4010D, T4020, T4210, T4220	206/L106	✗	P
		200, 270Dx, 280Dx, 400, 420D, 420Dx, 435Dx, 500, 520D, 520T, 530T, 531T, 535T, 535Tx, 555T, 555Tx, 565Tx, 585Tx, 585Tx1, 600, 635T, 635Tx, 635Tx1, 655Tx, 656Tx, 656Tx1, 675Tx, 690Tx, 700, 735Dx, 755Tx, 756Dx, 765Tx, 770Tx, 790Tx, 900, 985Tx, 990Tx2, A4170, B112, B142, B2, B2130, B2131, B2175, B245x, B2545, B2562, B2566, B256x, B2610, B2620, B2630, B3010D, B3020, B3020D, B5010, B6110D, B6210, C340, C350, C352, C353, C360, C4120, C4235, C5130, C5235, C6177, C6320, C6330, C6525, C6535, C6537, C6547, C6556, C6557, C6577, C6581, C6591, C6611, C6631, C6651, C7631, C7651, C7661, Celsius Mobile H, E330, E335, E340, E342, E350, E351, E360, E362, E370, E380, E5140, E5320, E5520, E6150, E6520, E6530, E6540, E6541, E6550, E6555, E6556, E6557, E6570, E6571, E6575, E6595, Exxx5, L440, L470, P1000, P1032, P1035, P1110, P1120, P1510D, P1610, P2000, P2040, P2046, P2110, P2120, P5010, P5010D, P5020, P5020D, P7010, P7010D, P7120, P7120D, P7230, Q2010, S2010, S2020, S2110, S4510, S4542, S4546, S4572, S5582, S6010, S6110, S6120, S6120D, S6210, S6220, S6230, S6231, S6240, ST5030, ST5030D, ST5031, ST5031D, ST5032, ST5032D, Stylistic 3400, Stylistic 3500, Stylistic CT2020, Stylistic LT C-500, Stylistic LT P-600, Stylistic ST4110, Stylistic ST4110P, Stylistic ST4120P, Stylistic ST4121P, Stylistic ST5010, Stylistic ST5010D, Stylistic ST5011, Stylistic ST5011D, Stylistic ST5020, Stylistic ST5020D, Stylistic ST5021, Stylistic ST5021D, Stylistic ST5022, Stylistic ST5022D, T3010, T3010D, U820	✗/✗	N	✗



AC wall



DC auto



DC air

Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal	Replacement	
90W AC - APA64U 90W AC/DC -APA64U	75W AC APA02AU	90W AC APA03AU

Manufacturer	Model Name	Series	Tip	Tip	Tip
Gateway	Gateway	400SD4, 400VTX, 4012GZ, 4024GZ, 4026GZ, 4028GZ, 405E, 405X, 450ROG, 450SX4, 4530GH, 4530GZ, 4535GZ, 4536GZ, 4538GZ, 4540GZ, 600YG2, 600YGR, M305, M500	206/L106	✗	P
	Solo	1100 Series, 1150, 1200, 1400, 1450, 2100 series, 2150 Series, 2200 series, 2300 series, 2500 series, 2550 Series, 3100 Series, 3150 Series, 5100 series, 5150 Series, 5300, 5350, 9100 Series, 9150, 9300 Series, 9500, 9550	206/L106	✗	P
HP	Business Tablet	TC4200	102/L107	✗	T
		TC4200	102/L107	✗	✗
		TC4400	203/L111	✗	✗
	Business Thin Client	2533t, 6720t	203/L111	✗	✗
	EliteBook	2530p, 2730p, 6930p	203/L111	✗	✗
	HP	510, 530, 550, L2000, L2005A3, L2005A4, L2098XX, L2099XX	102/L107	✗	T
		G60t, G70t	203/L111	✗	✗
	HP Compaq Business	6520s (Intel Graphic card), 6720s, NC4000, NC4010, NC4200, NC6000, NC6120, NC6200, NC6220, NC6230, NC8000, NW8000, NX5000, NX6100, NX6110, NX6115, NX6120, NX6125, NX7000, NX7010, NX7200, NX9020, NX9030, NX9040	102/L107	✗	T
		6520s (ATI Graphic card), 6820s, NX8220,	201/L107	✗	✗
		2230s, 2510p, 2710p, 6510b, 6515b, 6530b, 6531s, 6535b, 6710b, 6710s, 6712b, 6715b, 6715s, 6715sb, 6730b, 6730s, 6735b, 6735s, 6830s, 6910p, 8510p, 8510w, NC2400, NC4400, NC6140, NC6320, NC6400 (ATI Graphic card), NC6400 (Intel Graphic Card), NC6440, NC8230, NC8430, NW8240, NW8440, NX6310, NX6320, NX6325, NX7300, NX7400, NX8420, NX9420	203/L111	✗	✗
	Mini Netbook	NX9000, NX9005, NX9008, NX9010	206/L106	✗	P
		110-1008TU, 110-1106TU	102/L107	✗	T
		2133 Mini-Note, 2140	203/L111	✗	✗
	Omnibook	2000, 2100, 2103, 2105, 300, 3000, 3100, 3101, 4000, 4000C, 4100, 4101, 4103, 4105, 4150, 4150B, 425, 430, 500, 5000, 510, 530, 5500, 5700, 6000, 6000B, 6000C, 6100, 7100, 7103, 7150, 900, 900B, N3000, VT6200, XE, XE 4400 BTO, XE2, XE2-DB, XE2-DC, XE2-DD, XE2-DI, XE3, XE3B, XE3C, XE3-GD, XE3-GF, XE4100, XE4200, XE4400, XE4500, XE-DA, XT1000, XT1500, XT6050, XT6200	206/L106	✗	P
Pavillion	DV1000, DV1001AP, DV1002AP, DV1003AP, DV1004AP, DV1005AP, DV1006AP, DV1007AP, DV1008AP, DV1009AP, DV1010AP, DV1013AP, DV1014AP, DV1015AP, DV1016AP, DV1017AP, DV1018AP, DV1019AP, DV101EAP, DV1020AP, DV1021AP, DV1022AP, DV1023AP, DV1024AP, DV1025AP, DV1026AP, DV1027AP, DV1029AP, DV1030AP, DV1031AP, DV1100, DV1101AP, DV1102AP, DV1103AP, DV1104AP, DV1105AP, DV1106AP, DV1107AP, DV1108AP, DV1109AP, DV1110AP, DV1111AP, DV1112AP, DV1113AP, DV1115AP, DV1116AP, DV1117AP, DV1118AP, DV1119AP, DV1120AP, DV1121AP, DV1122AP, DV1123AP, DV1124AP, DV1125AP, DV1127AP, DV1128AP, DV1129AP, DV1130AP, DV1131AP, DV1132AP, DV1133AP, DV1134AP, DV1135AP, DV1136AP, DV1137AP, DV1139AP, DV1300, DV1301XX MV IUR, DV1302XX MV IUR, DV1311AP, DV1312AP, DV1313AP, DV1314AP, DV1315AP, DV1316AP, DV1317AP, DV1318AP, DV1319AP, DV1320AP, DV1321AP, DV1324AP, DV1325AP, DV1326AP, DV1327AP, DV1328AP, DV1329AP, DV1330AP, DV1331AP, DV1332AP, DV1333AP, DV1334AP, DV1335AP, DV1336AP, DV1338AP, DV1339AP, DV1340AP, DV1341AP, DV1342AP, DV1343AP, DV1344AP, DV1345AP, DV1346AP, DV1347AP, DV1348AP, DV1349AP, DV1350AP, DV1351AP, DV1352AP, DV1353AP, DV1354AP, DV1355AP, DV1356AP, DV1357AP, DV1358AP, DV1359AP, DV1360AP, DV1361AP, DV1362AP, DV1362TU, DV1363AP, DV1364AP, DV1365AP, DV1366AP, DV1367TU, DV1368TU, DV1369TU, DV1370TU, DV1371TU, DV1372TU, DV1373TU, DV1374TU, DV1375TU, DV1376TU, DV1379TU, DV1380TU, DV1381TU, DV1382TU, DV1383TU, DV1384TU, DV1385TU, DV1386TU, DV1387TU, DV1388TU, DV1389TU, DV1390TU, DV1391TU, DV1392TU, DV1393TU, DV1394TU, DV1395TU, DV1396TU, DV1399XX MV IUR, DV1600, DV1610TN, DV1738OD, DV2000, DV2000Z, DV2002TU, DV2017TU, DV2020TX, DV2023, DV2023TU, DV2029TU, DV2036TU, DV2045TU, DV2-1001AU, DV2111TX, DV2112TX, DV2133, DV2401TU, DV2402TU, DV2403TU, DV2404TU, DV2405TU, DV2501xx, DV2502TU, DV2505TU, DV2506xx, DV2508TU, DV2509TU, DV2510TU, DV2511TU, DV2512TU, DV2513TU, DV2514TU, DV2515TU, DV2516TU, DV2517TU, DV2518TU, DV2519TU, DV2520TU, DV2521TU, DV4000xx MV IUR, DV4001AP, DV4001xx MV IUR, DV4002AP, DV4003AP, DV4004AP, DV4004xx MV IUR, DV4005AP, DV4005xx MV IUR, DV4006AP, DV4006xx MV IUR, DV4007AP, DV4007xx MV IUR, DV4008AP, DV4009AP, DV4010AP, DV4011AP, DV4012AP, DV4013AP, DV4014AP, DV4015AP, DV4016AP, DV4017AP, DV4018AP, DV4019AP,	102/L107	✗	✗	



AC wall



DC auto



DC air

Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal	Replacement	
90W AC - AP64AU 90W AC/DC - AP64AU	75W AC APA02AU	90W AC APA03AU

Manufacturer	Model Name	Series	Tip	Tip	Tip
HP	Pavillion	DV4020AP, DV4021AP, DV4022AP, DV4023AP, DV4024AP, DV4025AP, DV4026AP, DV4100, DV4114, DV4117AP, DV4121AP, DV4126AP, DV4201TU, DV4201TX, DV4202TU, DV4202TX, DV4203TU, DV4203TX, DV4204TU, DV4204TX, DV4205TX, DV4206TU, DV4206TX, DV4207TU, DV4207TX, DV4208TX, DV4209TX, DV4210TX, DV4211TX, DV4212TX, DV4213TX, DV4214TX, DV4215TX, DV4216TX, DV4217TX, DV4218TX, DV4219TX, DV4220TX, DV4221TX, DV4222TX, DV4223TX, DV4224TX, DV4225TX, DV4288, DV4420, DV5000, DV5000T, DV5100, DV5101TU, DV5101TX, DV5102TU, DV5102TX, DV5103TX, DV5104TU, DV5104TX, DV5105TU, DV5105TX, DV5106TX, DV5107TX, DV5108TX, DV5109TX, DV5110TX, DV5112TX, DV5113TX, DV5114TX, DV5115TX, DV5116TX, DV5117TX, DV5118TX, DV5121TX, DV5123TX, DV5124TX, DV5125TX, DV5126TX, DV5127TX, DV5128TX, DV5129TX, DV5130TX, DV5131TX, DV5196XX, DV5197XX, DV5200, DV5200TU, DV5200TX, DV5201TU, DV5201TX, DV5202TU, DV5202TX, DV5203TU, DV5203TX, DV5204TU, DV5204TX, DV5205TX, DV5206TU, DV5206TX, DV5207TX, DV5208TX, DV5209TX, DV5210TX, DV5211TX, DV5212TX, DV5213TX, DV5214TX, DV5215TX, DV5216TX, DV5217TX, DV5218TX, DV5219TX, DV5220TX, DV5221TX, DV5222TX, DV5223TX, DV5224TX, DV5225TX, DV5226TX, DV5227TX, DV5228TX, DV5229TX, DV5230TX, DV5231TX, DV5232TX, DV5233TX, DV5235TX, DV5236TX, DV5237TX, DV6102OD, DV6128TU, DV6131OD, DV6200, DV6204AU, DV6501TU, DV6502TU, DV6503TU, DV6504TU, DV6506TU, DV6507TU, DV6508TU, DV6509TU, DV6599xx, DV6700T(Intel Graphic card), DV8000xx, DV8013xx, DV8040xx, DV8099xx, DV8200, DV8211TX, DV8218, DV8219, DV8308, DV8310TX, DV9598xx, DV9599xx, TX2-1015AU	102/L107	✗	✗
		ZE2001AP, ZE2001xxMV IUR, ZE2002AP, ZE2003AP, ZE2004AP, ZE2005AP, ZE2006AP, ZE2007AP, ZE2008AP, ZE2009AP, ZE2009XX MV IUR, ZE2009xxMV IUR, ZE2010AP, ZE2011AP, ZE2012AP, ZE2013AP, ZE2014AP, ZE2015AP, ZE2016AP, ZE2017AP, ZE2018AP, ZE2019AP, ZE2020AP, ZE2200, ZE2200T, ZE2200Z, ZE2201AP, ZE2201XX MV IUR, ZE2201xxMV IUR, ZE2202AP, ZE2203AP, ZE2204AP, ZE2205AP, ZE2206AP, ZE2207AP, ZE2208AP, ZE2209AP, ZE2209XX MV IUR, ZE2209xxMV IUR, ZE2210AP, ZE2211AP, ZE2212AP, ZE2296XX MV IUR, ZE2296xxMV IUR, ZE2297XX MV IUR, ZE2297xxMV IUR, ZE2298XX MV IUR, ZE2298xxMV IUR, ZE2299XX MV IUR, ZE2299xxMV IUR, ZE2401XT, ZE4901 MV IUR, ZE4902 MV IUR, ZE5526AP, ZT3050AP, ZT3301AP, ZV5203AP	102/L107	✗	P
		4316, 3010AP, 3011AP, 4523, 6100 Series, HDX9003TX, HDX9004TX, TX1000, TX1001AU, TX1001xx, TX1002AU, TX1002xx, TX1003AU, TX1003xx, TX1004AU, TX1005AU, TX1006AU, TX1007AU, TX1008AU, TX1014AU, TX1030IA, TX2011AU, TX2500Z, TX2502AU, TX2503AU, V5022AP, ZT3000, ZT3010, ZT3010AP, ZT3011AP, ZT3012AP, ZT3013AP, ZT3014AP, ZT3015AP, ZT3016AP, ZT3017AP, ZT3018AP, ZT3019AP, ZT3020, ZT3020AP, ZT3021AP, ZT3022AP, ZT3023AP, ZT3024AP, ZT3025AP, ZT3026AP, ZT3027AP, ZT3028AP, ZT3029AP, ZT3030AP, ZT3031AP, ZT3032AP, ZT3033AP, ZT3034AP, ZT3035AP, ZT3036AP, ZT3037AP, ZT3038AP, ZT3039AP, ZT3040AP, ZT3041AP, ZT3043AP, ZT3044AP, ZT3045AP, ZT3046AP, ZT3047AP, ZT3048AP, ZT3049AP, ZT3050AP, ZT3051AP, ZT3201AP, ZT3202AP, ZT3203AP, ZT3204AP, ZT3205AP, ZT3206AP, ZT3207AP, ZT3208AP, ZT3209AP, ZT3210AP, ZT3211AP, ZT3212AP, ZT3250xx, ZT3280, ZT3302, ZT3340, ZT3350, ZT3380	102/L107	✗	T
		DV2000T, DV2024TX, DV2040TX, DV2085, DV2113TU, DV2123TU, DV2222TX, DV2305TU, DV2308TX, DV2503XX, DV2521TX, DV2522TX, DV2529TX, DV2530TX, DV2533TX, DV2538TX, DV2609TX, DV2619TX, DV2632TX, DV2633TX, DV2637TX, DV2700TV (NVIDIA Graphic card), DV2701TX Special Edition, DV2739TX Special Edition, DV2740TX Special Edition, DV2753TX Special Edition, DV2754TX, DV2754TX Special Edition, DV2758TX Special Edition, DV2762TX Special Edition, DV2765TX Special Edition, DV2766TX Special Edition, DV2807TX, DV2808TX, DV2809TX, DV2813TX, DV2814TX, DV2817TX, DV2819TX, DV2820TX, DV2823TX, DV2825TX, DV2827TX, DV2828TX, DV2835TX, DV4000, DV6000, DV6000Z, DV6001XX, DV6113TX, DV6116TX, DV6121TX, DV6122TX, DV6129TX, DV6201TU, DV6207TX, DV6218TX, DV6221TX, DV6302TU, DV6304TX, DV6306TX, DV6404TU, DV6500, DV6500T, DV6500Z, DV6501TX, DV6502TX, DV6503TX, DV6504TX, DV6505TU, DV6505TX, DV6506TX, DV6507TX, DV6509TX, DV6510TX, DV6511TX, DV6512TX, DV6513TX, DV6514TX, DV6515TX, DV6516TX, DV6517TX, DV6518TX, DV6519TX, DV6520TX, DV6521TX, DV6522TX, DV6523TX, DV6524TX, DV6525TX, DV6526TX, DV6527TX, DV6528TX, DV6529TX, DV6531TX, DV6533TX, DV6534TX, DV6535TX, DV6536TX, DV6539TX, DV6540TX, DV6541TX, DV6542TX, DV6543TX, DV6544TX, DV6545TX, DV6546TX, DV6547TX, DV6548TX, DV6597xx, DV6598xx, DV6601AX, DV6614TX, DV6617TX, DV6700T(NVIDIA Graphic card), DV6709AX, DV6721TX, DV6724TX, DV6733TX, DV6746TX, DV6755TX, DV6757TX, DV6796TX, DV6835, DV6837TX, DV6838TX, DV8000, DV9000, DV9000T, DV9000Z, DV9001xx, DV9003xx, DV9007, DV9007TX, DV9008TX, DV9018, DV9018TX, DV9079, DV9095xx, DV9098xx, DV9203TX, DV9205TX, DV9218TX, DV9303TX, DV9304, DV9307TX, DV9500T, DV9500Z, DV9501TX, DV9502TX, DV9503TX, DV9504TX, DV9505TX, DV9506TX, DV9507TX, DV9508TX, DV9509TX, DV9511TX, DV9512TX, DV9513TX, DV9514TX, DV9516TX, DV9517TX, DV9518TX, DV9519TX, DV9520TX, DV9521TX, DV9596xx, DV9613TX, DV9615TX, DV9630, DV9700, DV9700T, DV9722TX, DV9724TX, DV9725TX, DV9748TX, DV9822TX, TX1219AU	201/L107	✗	✗
		DV3-1000 series, DV3-2002TU, DV3-2007TX, DV3504TX, DV3505TX, DV3506TX, DV3507TX, DV3522TX, DV3528TX, DV3529TX, DV3530TX, DV3534TX, DV3535TX, DV3539TX, DV3540TX, DV3Z series, DV4-1000, DV4-1004TU, DV4-1015TX, DV4-1016TX, DV4-1041TX, DV4-1048TX, DV4-1049TX, DV4T-1000, DV5-1004TX, DV5-1007TX, DV5-1009TX, DV5-1010TX, DV5-1019TX, DV5-1020TX, DV5-1045TX, DV5-1046TX, DV5-1050TX, DV5-1053TX, DV5-1054TX, DV5-1055TX, DV5-1140TX, DV6-1107AX, DV6-1129TX, DV6-1130TX, DV6-1207AX, DV6-1214AX, DV6-1244TX, DV6-1246TX, DV6-1247TU, DV7-1000, DV7-1002TX, DV7-1005TX, DV7-1014TX, DV7-1015TX, DV7-1019TX, DV7-1026TX, DV7-1104TX, DV7-1105TX, DV7-1107TX, DV7-2012TX, DV7-2014TX, DV7-2022TX, DV7Z-1000	203/L111	✗	✗



AC wall



DC auto



DC air

Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - AP64AU	75W AC APA02AU	90W AC APA03AU	
90W AC/DC - AP164U			

Manufacturer	Model Name	Series	Tip		
			Tip	Tip	Tip
HP	Pavillion	2105, 3101, 4101, 4103, 4105, 5159, N3110, N3150, N3190, N3210, N3215, N3220, N3250, N3270, N3290, N3295, N3310, N3330, N3350, N3370, N3380, N3390, N3402, N3410, N3438, N3478, N3490, N5000 BTCCO, N5124, N5125, N5130, N5135, N5140, N5150, N5159, N5170, N5190, N5195, N5210, N5221, N5240, N5241, N5250, N5261, N5270, N5271, N5290, N5295, N5310, N5311, N5331, N5340, N5341, N5350, N5351, N5361, N5371, N5381, N5390, N5401, N5402, N5402L, N5412, N5415, N5420, N5421, N5421L, N5422, N5422L, N5425, N5430, N5431L, N5435, N5440, N5441, N5442, N5444, N5445, N5450, N5451, N5452, N5454, N5455, N5461, N5462, N5470, N5472, N5474, N5475, N5481, N5482, N5484, N5490, N5491, N5495, N5511L, N5584, N6190, N6195, N6300 BTO, N6395, N6396, N6397, N6398, N6399, N6400, N6401, N6402, N6403, N6404, N6490, XF125, XF145, XF235, XF255, XF315, XF325, XF328, XF335, XH136, XH156, XH176, XH215, XH216, XH226, XH355, XH365, XH395, XH455, XH485, XH525, XH535, XH545, XH555, XH575, XH625, XH675, XT115, XT118, XT125, XT128, XT155, XT178, XT183, XT188, XT236, XT276, XT345, XT375, XT395, XT412, XT4345QV, XT512, XT5300, XT5335QV, XT5366, XT5377, XT5377QV, XT545, XT555, XT565, XT575, XT585, XT595, XU/ZU BTCCO, XU155, XZ133, XZ148, XZ163, XZ168, XZ185, XZ275, XZ295, XZ335, XZ355, ZE1000, ZE1110, ZE1115, ZE1145, ZE1201, ZE1202, ZE1210, ZE1230, ZE1250, ZE1260, ZE4000, ZE4101, ZE4102, ZE4103, ZE4105, ZE4111, ZE4115, ZE4120, ZE4123, ZE4125, ZE4130, ZE4133, ZE4140, ZE4145, ZE4200, ZE4201, ZE4202, ZE4204, ZE4206, ZE4207, ZE4208, ZE4209, ZE4210, ZE4211, ZE4214, ZE4218, ZE4219, ZE4220, ZE4221, ZE4222, ZE4224, ZE4228, ZE4229, ZE4230, ZE4231, ZE4232, ZE4234, ZE4236, ZE4239, ZE4240, ZE4241, ZE4251, ZE4258, ZE4261, ZE4268, ZE4271, ZE4274, ZE4278, ZE4281, ZE4282, ZE4284, ZE4288, ZE4292, ZE4294, ZE4298, ZE4301, ZE4305, ZE4307, ZE4308, ZE4310, ZE4311, ZE4312, ZE4313, ZE4314, ZE4315, ZE4316, ZE4317, ZE4318, ZE4319, ZE4320, ZE4321, ZE4323, ZE4325, ZE4330, ZE4332, ZE4333, ZE4334, ZE4335, ZE4336, ZE4345, ZE4347, ZE4348, ZE4349, ZE4351, ZE4352, ZE4353, ZE4354, ZE4355, ZE4356, ZE4357, ZE4360, ZE4365, ZE4367, ZE4375, ZE4384, ZE4385, ZE4386, ZE4400, ZE4401, ZE4402, ZE4410AP, ZE4412AP, ZE4413AP, ZE4414AP, ZE4427, ZE4500, ZE4520AP, ZE4521AP, ZE4522AP, ZE4523AP, ZE4540, ZE4546, ZE4547, ZE4551, ZE4560, ZE4600, ZE4610, ZE4700, ZE4800, ZE5000, ZE5030, ZE5155, ZE5160, ZE5165, ZE5170, ZE5185, ZE5190, ZE5200, ZE5207, ZE5217, ZE5228, ZE5232, ZE5236, ZE5238, ZE5240, ZE5242, ZE5244, ZE5250, ZE5252, ZE5258, ZE5262, ZE5270, ZE5279, ZE5300, ZE5320AP, ZE5345, ZE5375, ZE5385, ZE5395, ZE5400, ZE5470, ZE5490, ZE5500, ZE5515AP, ZE5575, ZE5600, ZE5603AP, ZE5604, ZE5604AP, ZE5605AP, ZE5608AP, ZE5611AP, ZE5612AP, ZE5613AP, ZE5616AP, ZE5620, ZE5700, ZE5749, ZT1000-IB BTCCO, ZT1114, ZT1120, ZT1121, ZT1121S, ZT1122, ZT1122S, ZT1125, ZT1130, ZT1131, ZT1131S, ZT1132, ZT1132S, ZT1135, ZT1141, ZT1142, ZT1145, ZT1150, ZT1151, ZT1152, ZT1155, ZT1161, ZT1162, ZT1170, ZT1171, ZT1172, ZT1175, ZT1180, ZT1181, ZT1182, ZT1185, ZT1190, ZT1192, ZT1201, ZT1201S, ZT1210, ZT1211, ZT1213, ZT1230, ZT1231S, ZT1233, ZT1235, ZT1243, ZT1250, ZT1260, ZT1261, ZT1270, ZT1271, ZT1290, ZT1331, ZU1155, ZU1175, ZU175	206/L106	✘	P
	Special Edition	L2000, L2005A3 MV IUR, L2005A4 MV IUR, L2098XX MV IUR, L2099XX MV IUR	102/L107	✘	T
	TouchSmart	TX2- series, TX2z series	102/L107	✘	✘
IBM/ Lenovo	3000	C100, C200, C205, N100 (Intel Graphic card), N100 (NVIDIA Graphic card), N200 (Intel Graphic card), N200 (NVIDIA Graphic card), V100, V200	204/L112	✘	R
		Y410	206/L106	✘	P
	IdeaPad	U110, U330, Y430, Y510, Y530, Y650, Y710, Y730	206/L106	✘	P
	IdeaPad Netbook	S10, S10e	206/L106	✘	P
	ThinkPad	240, 240X, 290, 365, 365XD, 380, 380D, 380E, 380ED, 380XD, 380Z, 385, 385D, 385ED, 385XD, 390, 390E, 390X, 560, 560E, 560X, 560Z, 570, 600, 600E, 600X, 701, 770, 770E, 770ED, 770X, 770Z, A20, A20m, A20p, A21, A21e, A21m, A21p, A22, A22e, A22m, A22p, A30, A30p, A31, A31p, A50, A50p, A51p, i1200, i1300, i1400-2621, i1500-2621, i1720, i1721, R30, R31, R32, R40, R40e, R50, R50e, R50p, R51, R51e, R52, T20, T21, T22, T23, T30, T40, T40p, T41, T41p, T42, T42p, T43, T43p, TransNote, X Series Tablet, X20, X21, X22, X23, X24, X30, X31, X32, X40, X41, X41 Tablet	104/L105	P	✘
		G50, R400, R500, R60, R60e, R61 (Intel Graphic card), R61 (NVIDIA Graphic card), R61e, R61i, SL300 (Intel Graphic card), SL300 (NVIDIA Graphic card), SL400 (Intel Graphic card), SL400 (NVIDIA Graphic card), SL500 (Intel Graphic card), SL500 (NVIDIA Graphic card), T400 (Intel Graphic card), T400 (NVIDIA Graphic card), T500 (ATI Graphic card), T500 (Intel Graphic card), T60 (ATI Graphic card), T60 (Intel Graphic card), T60p, T61 (Intel Graphic card), T61 (NVIDIA Graphic card), T61p (Intel Graphic card), T61p (NVIDIA Graphic card), W500, X200, X200S, X300, X301, X60, X60 Tablet, X60s, X61 Tablet, X61s, X61t, Z60m, Z60t, Z61e, Z61m, Z61p, Z61t	204/L112	✘	R
	1400-2611, 1500-2611, 310, 310D, 310E, 310ED	206/L106	✘	U	
	ThinkPad Reserve	Cingular Edition, Verizon Edition	204/L112	✘	R



AC wall



DC auto



DC air

Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - APA64AU	75W AC APA02AU	90W AC/DC - APA64AU	90W AC APA03AU

Manufacturer	Model Name	Series	Tip	Tip	Tip
Leader Computers	COMPANION 210	Z96SP	206 / L106	✗	✗
	COMPANION 212	Z96SP	206 / L106	✗	✗
	COMPANION 214	Z96SP	206 / L106	✗	✗
	EX600	MS-1636	206 / L106	✗	✗
	EX620	MS-1674	206 / L106	✗	✗
	GX620	MS-1651 (90 Watt version only)	206 / L106	✗	✗
	M670	MS-1632	206 / L106	✗	✗
	U100	NO11	206 / L106	✗	✗
	VR601	MS-163C	206 / L106	✗	✗
	VR630	MS-1672	206 / L106	✗	✗
	VR705	MS-171F	206 / L106	✗	✗
LG	F1	F1-2224A, F1-2226A	201/L107	✗	✗
	LE Series	LE50-5	201/L107	✗	✗
	LM Series	LM50, LM60 Express	201/L107	✗	✗
	LS Express	LS55, LS70	207/L108	✗	T
	LS Series	LS70-FLA4PA	201/L107	✗	✗
	LS Series	LS50-1, LS50-2, LS50-3, LS50-4, LS50-5, LS50-UK2A, LU-20 Tablet	207/L108	✗	T
	LT Series	LT19	207/L108	✗	T
	LW Series	LW20-22, LW40, LW60, LW65, LW70, LW75, LW80	201/L107	✗	✗
	Netbook	X110	206/L106	✗	P
	Pro	M1-M2FTV, P1, P1-52A7A, P1-J101A, P1-J102A, P1-J226A, P1-J2A8A, P1-J2B8A, P1-J5C6A, P1-J7P1A, P1-JUWSA, P1-JWS1A, P1-JWS2A, P1-KB10A, P1-KB11A, P1-KB20A, S1-MMNPA3, S1-P723A, Z1-A555P	201/L107	✗	✗
Macron		M363C, M540G, M540N, M550G, M550N, M551N, NW120, NW150, NX150	104/L105	P	✗
MSI	Netbook	EX300-018US, EX300-024US, EX620-IWIUS, EX625-227US, GT627-216US, GT627-218US, GX620-001US, GX620-038US, GX620-098US, PR201-013US, PR201-019US, PR201-Blue, PR201-Pink, PX600-008US, VR220-017US, VR601, VR705, X320, X340-021US, X340-023US	206/L106	✗	✗
	Wind Netbook	U100, U120, U90	206/L106	✗	✗



AC wall



DC auto



DC air

Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - AP64AU	75W AC - APA02AU	90W AC/DC - AP164U	90W AC - APA03AU

Manufacturer	Model Name	Series	Tip	Tip	Tip
NEC	LaVie	C Series, F Series, G Series, J Series, L Series, M Series, ME Series, N Series, Pro Series, T Series	206/L106	✗	P
	Pocket Gear	MC/PG5000, MC/PG7000	206/L106	✗	P
	Ready	220T, 230T, 330T, 340T, 360T, 440T	206/L106	✗	P
	Versa	2400, 2500, 2500CD, 2505, 2530, 4000, 4000 Series, 4000C, 4000D, 4000Hs, 4050C, 4050D, 4050H, 4080H, 4200, 4230, 500, 5000, 5060, 5060X, 5080, 5080X, 550D, A2100, C140, C150, C160, E120, E200, E2000, E3100, E3100-1812DW, E3100-1813DR, E600, E6000, E6000X, E6200, E6200-1703DR, E6210, E6210-1604DR, E6210-1627DR, E6210-1809DR, E6210-1810DR, E6210-1811DR, E6300, E6300-1504DR, E6300-1803DR, E6300-2201DR, E6310, E6310-2000DR, E680, FM320, FM500, FP520, FS800, IGO3000, IGO5000, IGO6000, L2100, L2100-1605DR, L2100-1606DR, L2100-1803DR, L2200-1802DR, L320, M300, M320, M3210, M440, M450, M500, M54, M540, P440, P520, P600, P700, P7200, P7200-1607DR, P7200-1800DR, P9110, P9110-1500DR, P9110-1800DR, P9110-2203DR, Premium, S1100, S800, S820, S940, S970, T400, T400S820, VersaNote, VX	206/L106	✗	P
	Versa	2000C, 2000D, 2205C, 2250, 6000, 6000H, 6010H, 6030H, 6030X, 6050 Series, 6050MH, 6050MT, 6050MX, 6060, 6200 Series, 6200MX, 6200NT, 6220, 6230, 6260	✗	✗	S
	VersaPro	VJ13M/AF-T, VJ13M/DF-R, VJ13M/RF-R, VJ13M/RX-R, VJ16F/RF-R, VJ16F/RX-R, VJ17F/AF-T, VJ17F/AG-T, VJ17F/DF-R, VJ17F/DG-R, VJ18F/RF-R, VJ20F/AE-T, VJ20F/AF-T, VJ20F/AG-T, VJ20F/DF-R, VJ20F/DG-R, VY13M/AF-T, VY13M/DF-R, VY13M/EF-R, VY13M/EX-R, VY13M/RF-R, VY13M/RX-R, VY16F/EF-R, VY16F/EX-R, VY16F/RF-R, VY16F/RX-R, VY17F/AF-T, VY17F/AG-T, VY17F/DF-R, VY17F/DG-R, VY18F/RF-R, VY20F/AE-T, VY20F/AF-T, VY20F/AG-T, VY20F/DF-R, VY20F/DG-R	206/L106	✗	P
	VersaPro NX	LW23C/52, LW23D, LW26H, LW30H, LW33H	206/L106	✗	P
Optima	Centoris	25911, E+ Series, EF6C, EW1, EW2G, F Series, G Series, L2400, TW3, V470, V662, V670, V862, V870, W Series, ZW1, ZW9	206/L106	✗	P
	ProLite	K Series	207/L108	✗	T
Packard Bell	EasyNote	1800DR, BG46, C16, C3, MB88-003, MX37-U-041, R8, SB88, XS20	206/L106	✗	P
		G5	207/L108	✗	T
Panasonic	Toughbook	52, 74, CF19, CF29, CF30, CF50, CF51, CF73, CFR1, CFR4, CFR7, CFT1, CFT2, CFW2, CFW4, T4, T5, T7, T8, W5, W7, W8, Y4, Y5, Y7	104/I105	P	✗
		CFV21, CFV21P	209/I110	✗	N
		CF01, CF11, CF17, CF170, CF25, CF27, CF270, CF28, CF33, CF34, CF35, CF37, CF370, CF380, CF41, CF45, CF47, CF48, CF61, CF62, CF63, CF71, CF72, CFM34, CFR, CFT, CFV25, CFV41	✗/✗	N	✗
Toughbook Netbook	H1, U1	104/I105	P	✗	
Samsung	NoteMaster	486C/25	205/I104	M	✗
	Samsung	P560-54G, P560-54P	✗/✗	N	✗
	Sens	500, 810	209/I110	✗	N
	Sens	700, 800	✗/✗	N	✗
	SensPro	500, 505, 520, 521, 525	209/L110	✗	N
Sony	PictureBook	C1X	✗/✗	N	✗
	Vaio	705, 707, 717, 719, 729, 731, 735, 748, 800, 808, 81, 812, 818, 838, A17GP, A19GP, A29GP, A29TP, C1XW, F150, F160, F180, F190, F250, F270, F280, F290, F304, F305, F309, F340, F350, F360, F370, F390, F400, F400LT, F403, F409, F420, F430, F450, F480, F480K, F490K, F520, F540, F540K, F560, F560K, F580, F580K, F590, F590K, F630, F660, F670, F680, F690, F701, F707, F709, F709K, F801, F801A, F807, F807K, F808K, F809K, FR102, FR105, FR130, FR700H, FX101, FX103, FX105K, FX108K, FX109K, FX120, FX140, FX150, FX170, FX190, FX200, FX201, FX203, FX203K, FX205K, FX209K, FX220K, FX270, FX301, FX401, FX405, FX501, FX502, FX505, FX601, FX602, FX604, FX605, FX701, FX702, FX705, FX770K, FX800, FX801, FX802, FX804, FX805, FX880K, FX902P, FX905P, FXA32,	209/L110	✗	N



AC wall



DC auto



DC air

Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - AP64AU	75W AC APA02AU	90W AC APA03AU	
90W AC/DC - AP64AU			

Manufacturer	Model Name	Series	Tip	Tip	Tip
Sony	Vaio	FXA33, FXA36, FXA63, GRS100, GRS150, GRS515M, GRS515R, GRS515SP, GRS614MP, GRS700, GRS700K15, GRX316SP, GRX3P, GRX416SP, GRX500, GRX516SP, GRX520, GRX520/B, GRX550, GRX560, GRX570, GRX580K, GRX590, GRX5P, GRX600, GRX650, GRX670, GRX690, GRX700, NV100, NV105, NV109M, NV170, NV190, NV200, NV209, NV309, NVR23, PCG-7N2M, PCG-F670T, PCG-FR215E, PCG-FR215H, PCG-FR215M, PCG-FR215S, PCG-FR295MP, PCG-FR315M, PCG-FR700, PCG-FR700H, PCG-FR700S, PCG-FR720, PCG-FR720L, PCG-FR720S, PCG-FR820L, PCG-FR820S, PCG-FR825P, PCG-FR825SP, PCG-FRV25, PCG-FX240, PCG-FX240K, PCG-FX390, PCG-FX390K, PCG-FX390P, PCG-FX770TK, PCG-FX800, PCG-FX880K, PCG-FX900, PCG-FX900H, PCG-FX950, PCG-FX950H, PCG-FX990, PCG-FXA10, PCG-FXA10H, PCG-GRX1P, PCG-GRX3HP, PCG-GRX3LP, PCG-GRX3P, PCG-GRX5LP, PCG-GRX5P, PCG-NV190, PCG-NV7EL, PCG-NV7L, PCG-R505AFH, PCG-R505AFT, PCG-R505AGT, PCG-R505CT, PCG-R505DT, PCG-R505GL, PCG-R505GLK, PCG-R505MFL, PCG-R505MGH, PCG-R505MGL, PCG-R505MP, PCG-R505TFL, PCG-R505TFP, PCG-TR5GP, PCG-XE17, PCG-Z505GAT, PCG-Z505GATH, PCG-Z505GATHM, PG32, QR10, QR20, R500, R505B/P, R505CT, R505D, R505DS, R505DSK, R505DT, R505J, R505MP, R505MXC, R505T, R505TE, R505TEK, R505TFP, R505TS, R505TXCP, R505TZCP, R600HEK, R600HEP, R600HFPD, R600HMPD, R600MX, VGN-A115B, VGN-A115S, VGN-A115Z, VGN-A117S, VGN-A130, VGN-A130B, VGN-A130B28, VGN-A130P, VGN-A140, VGN-A140B, VGN-A140P, VGN-A150, VGN-A15GP, VGN-A15LP, VGN-A160, VGN-A170, VGN-A170B, VGN-A170P, VGN-A17GP, VGN-A17LP, VGN-A17SP, VGN-A190, VGN-A195EP, VGN-A195HP, VGN-A197VP, VGN-A197XP, VGN-A19GP, VGN-A19LP, VGN-A19SP, VGN-A215M, VGN-A215Z, VGN-A217M, VGN-A217S, VGN-A21C, VGN-A230B1, VGN-A230P, VGN-A240, VGN-A250, VGN-A260, VGN-A270, VGN-A270B, VGN-A270P, VGN-A290, VGN-A295HP, VGN-A297XP, VGN-A29LP, VGN-A29SP, VGN-A317M, VGN-A317S, VGN-A397XP, VGN-A39GP, VGN-A417M, VGN-A417S, VGN-A497XP, VGN-A49GP, VGN-A517B, VGN-A517M, VGN-A517S, VGN-A59GP, VGN-A600, VGN-A60091, VGN-A600B, VGN-A600P, VGN-A60GP, VGN-A617B, VGN-A617M, VGN-A617S, VGN-A690, VGN-A790, VGN-AR38G, VGN-AX570G, VGN-AX580G, VGN-BX143, VGN-BX145CP, VGN-BX168GP, VGN-BX194VP, VGN-BX195EP, VGN-BX195VP, VGN-BX195XP, VGN-BX196SP, VGN-BX196VP, VGN-BX196XP, VGN-BX197XP, VGN-BX294VP, VGN-BX295SP, VGN-BX295VP, VGN-BX296VP, VGN-BX296XP, VGN-BX297XP, VGN-BX394VP, VGN-BX396BP, VGN-BX396VP, VGN-BX396XP, VGN-BX397XP, VGN-BX41XN, VGN-BX540B, VGN-BX541B, VGN-BX543B, VGN-BX546B, VGN-BX560B, VGN-BX561B, VGN-BX563B, VGN-BX565B, VGN-BX567B, VGN-BX570B, VGN-BZ15GN, VGN-C140G/B, VGN-C150P/B, VGN-C190, VGN-C190P/H, VGN-C1S/G, VGN-C1S/H, VGN-C1S/P, VGN-C1S/W, VGN-C1Z/B, VGN-C210E/H, VGN-C21GH, VGN-C220E/H, VGN-C240E/B, VGN-C250N/B, VGN-C25G, VGN-C290, VGN-C291NW/H, VGN-C2S/G, VGN-C2S/H, VGN-C2S/L, VGN-C2S/P, VGN-C2S/W, VGN-C2Z/B, VGN-C31GH/W, VGN-CR22G/B, VGN-CR25GN, VGN-CR25GW, VGN-CR32G, VGN-CR343NB, VGN-CR353B, VGN-CR353L, VGN-CR353N, VGN-CR353P, VGN-CR353Q, VGN-CR353S, VGN-CR353T, VGN-CR353W, VGN-CS26GP, VGN-CS26GQ, VGN-CS26GR, VGN-CS26GW, VGN-CS35GNB, VGN-CS36GJC, VGN-CS36GJL, VGN-CS36GJJ, VGN-CS36GJP, VGN-CS36GJQ, VGN-CS36GJR, VGN-CS36GJT, VGN-CS36GJU, VGN-CS36GJW, VGN-FE11S, VGN-FE25TP, VGN-FE28B, VGN-FE28H, VGN-FE31B, VGN-FE31H, VGN-FE31M, VGN-FE31Z, VGN-FE41E, VGN-FE41M, VGN-FE41S, VGN-FE41Z, VGN-FE45G, VGN-FE48G, VGN-FE550G, VGN-FE570G, VGN-FE590GC, VGN-FE590P03, VGN-FE590PA, VGN-FE590PB, VGN-FE590PC, VGN-FE660G, VGN-FE670G, VGN-FE690, VGN-FE690GB, VGN-FE770G, VGN-FE780G, VGN-FE790, VGN-FE790GN, VGN-FE790PL, VGN-FE870E/H, VGN-FE880E/H, VGN-FE890, VGN-FE890N/H, VGN-FJ170/B, VGN-FJ180P/G, VGN-FJ180P/L, VGN-FJ180P/R, VGN-FJ180P/W, VGN-FJ1S/W, VGN-FJ1Z/W, VGN-FJ250P/B, VGN-FJ270P/B, VGN-FJ290, VGN-FJ290P1/G, VGN-FJ290P1/L, VGN-FJ290P1/R, VGN-FJ290P1/V, VGN-FJ290P1/W, VGN-FJ3S/W, VGN-FJ56C, VGN-FJ56G, VGN-FJ57C, VGN-FJ57SP, VGN-FJ58C, VGN-FJ58GP, VGN-FJ58SP, VGN-FJ66GP, VGN-FJ66GP/W, VGN-FJ67GP/W, VGN-FJ68GP, VGN-FJ68GP/W, VGN-FJ77GP/B, VGN-FJ78GP/B, VGN-FJ78GP/W, VGN-FJ78GPL, VGN-FJ78GRP, VGN-FJ79TP/V, VGN-FJ79TP/W, VGN-FR820, VGN-FR825P, VGN-FS115B, VGN-FS115E, VGN-FS115M, VGN-FS115S, VGN-FS115Z, VGN-FS15C, VGN-FS15GP, VGN-FS15LP, VGN-FS15SP, VGN-FS18CP, VGN-FS18GP, VGN-FS18LP, VGN-FS18SP, VGN-FS195VP, VGN-FS195XP, VGN-FS215B, VGN-FS215E, VGN-FS215M, VGN-FS215MR, VGN-FS215S, VGN-FS215SR, VGN-FS215Z, VGN-FS25C, VGN-FS25GP, VGN-FS25SP, VGN-FS285B, VGN-FS285E, VGN-FS285H, VGN-FS285M, VGN-FS28C, VGN-FS28GP, VGN-FS28SP, VGN-FS295VP, VGN-FS295XP, VGN-FS315B, VGN-FS315E, VGN-FS315H, VGN-FS315M, VGN-FS315MR, VGN-FS315S, VGN-FS315Z, VGN-FS35C, VGN-FS35GP, VGN-FS35SP, VGN-FS38C, VGN-FS38GP, VGN-FS38SP, VGN-FS395VP, VGN-FS415B, VGN-FS415E, VGN-FS415M, VGN-FS415S, VGN-FS485B, VGN-FS48GP, VGN-FS495VP, VGN-FS500, VGN-FS500B, VGN-FS500P, VGN-FS500P12, VGN-FS515B, VGN-FS515E, VGN-FS515H, VGN-FS520B, VGN-FS530B, VGN-FS540P, VGN-FS550, VGN-FS550F, VGN-FS550P, VGN-FS570, VGN-FS610FP, VGN-FS615FP, VGN-FS620P/W, VGN-FS625B/W, VGN-FS630/W, VGN-FS635B/W, VGN-FS640/W, VGN-FS640FP, VGN-FS645P/H, VGN-FS650F, VGN-FS655FP, VGN-FS660/W, VGN-FS660P/W, VGN-FS670FG, VGN-FS675P/H, VGN-FS680/W, VGN-FS690, VGN-FS690B, VGN-FS690P, VGN-FS710/W, VGN-FS710FP, VGN-FS715/W, VGN-FS715F, VGN-FS720/W, VGN-FS730/W, VGN-FS730F, VGN-FS740/W, VGN-FS740FP, VGN-FS742/W, VGN-FS745P/H, VGN-FS750F, VGN-FS750P/W, VGN-FS755FP, VGN-FS760/W, VGN-FS770/W, VGN-FS770FG, VGN-FS775P/H, VGN-FS790, VGN-FS810/W, VGN-FS810FP, VGN-FS812F, VGN-FS815F, VGN-FS830/W, VGN-FS840/W, VGN-FS850, VGN-FS850/W, VGN-FS850P, VGN-FS850P/W, VGN-FS875P/H, VGN-FS8900, VGN-FS8900P3, VGN-FS8900P4, VGN-FS8900P5, VGN-FS920, VGN-FS930F, VGN-FS940, VGN-FS960P, VGN-FS970P, VGN-FS980, VGN-FS990, VGN-FW15GB, VGN-FW15GW, VGN-FW16GW, VGN-FW17GUH, VGN-FW33GW, VGN-FW37, VGN-FW43GB, VGN-FW43GW, VGN-FW45GJB, VGN-FW46GJB, VGN-FW47GYH, VGN-FZ25G, VGN-FZ27G, VGN-FZ28G, VGN-FZ323G, VGN-FZ37G, VGN-FZ38GU, VGN-FZ55GN, VGN-N110G/W, VGN-N11H/W, VGN-N11M/W, VGN-N11S/W, VGN-N130G/W, VGN-N130P/B, VGN-N150G/W, VGN-N150P/B, VGN-N160G/W, VGN-N170G/T, VGN-N170G/W, VGN-N19EP/B, VGN-N19VP/B, VGN-N21E/W, VGN-N21M/W, VGN-N21S/W, VGN-N220E/B, VGN-N220E/W, VGN-N230E/B, VGN-N230E/T, VGN-N230E/W, VGN-N230N/B, VGN-N250E/W, VGN-N250N/B, VGN-N270E/T, VGN-N270E/W, VGN-N27GH, VGN-N29V/B, VGN-N320E/B, VGN-N320E/W, VGN-N350E/B, VGN-N350E/T, VGN-N350E/W, VGN-N37GHB, VGN-NR37GS, VGN-NW15GS, VGN-NW15GT, VGN-NW15GW, VGN-NW17GJS, VGN-S380, VGN-S380B, VGN-S38GP, VGN-S38GP/B, VGN-S38LP/B, VGN-S38SP, VGN-S3HP,	209/L110	✗	N



AC wall



DC auto



DC air

Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - AP64AU	75W AC APA02AU	90W AC APA03AU	
90W AC/DC - AP64AU			

Manufacturer	Model Name	Series	Tip	Tip	Tip
Sony	Vaio	VGN-S3VP, VGN-S3XP, VGN-S430P/S, VGN-S45, VGN-S45SP, VGN-S46, VGN-S460, VGN-S460/B, VGN-S460P/B, VGN-S46GP/S, VGN-S470P/S, VGN-S470P/SKIT, VGN-S470P/SKIT7, VGN-S47SP, VGN-S48, VGN-S480, VGN-S480B, VGN-S48GP/B, VGN-S49, VGN-S4HP, VGN-S4HP/B, VGN-S4HRP/B, VGN-S4M/S, VGN-S4VP/B, VGN-S4XP, VGN-S4XRP/B, VGN-S55, VGN-S550P/S, VGN-S55SP/S, VGN-S56, VGN-S560P/B, VGN-S56GP/S, VGN-S570P/S, VGN-S57SP/B, VGN-S58, VGN-S580, VGN-S58GP/B, VGN-S59, VGN-S5HP, VGN-S5M/S, VGN-S5VP, VGN-S5XP/B, VGN-S660/B, VGN-S67GP/S, VGN-S67TP, VGN-SR16GNB, VGN-SR16GNP, VGN-SR16GNS, VGN-SR16NB, VGN-SR46GDB, VGN-SR46GDP, VGN-SZ110/B, VGN-SZ120P, VGN-SZ120P/B, VGN-SZ140, VGN-SZ140PC, VGN-SZ140PD, VGN-SZ160P/C, VGN-SZ17G, VGN-SZ210P/B, VGN-SZ220/B, VGN-SZ230P/B, VGN-SZ23TP/B, VGN-SZ240, VGN-SZ250P/C, VGN-SZ260P, VGN-SZ26TP/C, VGN-SZ270P/C, VGN-SZ280P/C, VGN-SZ281P/X, VGN-SZ28TP/C, VGN-SZ2VP/X, VGN-SZ320P/B, VGN-SZ330P/B, VGN-SZ340, VGN-SZ360P/C, VGN-SZ370P/C, VGN-SZ381P/X, VGN-SZ38GP, VGN-SZ390, VGN-SZ390PW1, VGN-SZ3HP/B, VGN-SZ3VP/X, VGN-SZ3WVP/X, VGN-SZ3XP/C, VGN-SZ3WVP/C, VGN-SZ430N/B, VGN-SZ43NB, VGN-SZ43GN, VGN-SZ440, VGN-SZ44GN, VGN-SZ450N/C, VGN-SZ453NB, VGN-SZ460N/C, VGN-SZ470N/C, VGN-SZ480, VGN-SZ483NC, VGN-SZ48GN, VGN-SZ491N/X, VGN-SZ4MN/B, VGN-SZ4VN/X, VGN-SZ4VWN/X, VGN-SZ4XWN/C, VGN-SZ55GNB, VGN-SZ5MN/B, VGN-SZ75GNB, VGN-SZ79GNC, VGN-TX56GN, VGN-Z16GNB, VGN-Z17GNB, VGN-Z46GDB, VGN-Z46GDU, VGN-Z47GDX, VGN-Z48GDX, X18, X29, X9, XE17, XE7, XG18, XG19, XG28, XG28K, XG29, XG29K, XG38, XG39, XG39K, XG500, XG700, XG9, Z505, Z505FA, Z505GA, Z505GAH, Z505GAM, Z505HE, Z505HS, Z505HSK, Z505JE, Z505JEK, Z505JS, Z505JSK, Z505LE, Z505LEK, Z505LS, Z505LSK, Z505R, Z505RX, Z505S, Z505SX, Z600HEK, Z600LEK, Z600NE, Z600NEK, Z600RE, Z600TEK	209/L110	✗	N
		B55T, C1MHP, C1MT, C1MT1, GR100, GR100K, GR114EK, GR114MK, GR114SK, GR150K, GR170K, GR200, GR200K, GR200P, GR214CP, GR214EP, GR214MP, GR215MP, GR215SP, GR250, GR250K, GR250P, GR270, GR270K, GR270P, GR290, GR290K, GR290P, GR300, GR314MP, GR315MP, GR370, GR390, GR414SP, POC-C1MAH, POC-C1MEL, POC-C1MTL, POC-SR19GKRT, POC-SR19GT, POC-SRX55H, POC-SRX55L, POC-SRX55TH, POC-SRX55TL, POC-SRX87, POC-TR1, POC-TR1L, POC-TR1MP, POC-TR1S, POC-TR2, POC-TR2L, POC-TR2MP, POC-TR2S, POC-TR3, POC-TR3AP3, POC-TR3S, POC-TR5AP, POC-TR5L, POC-TR5MP, POC-V505AK, POC-V505ECP14, POC-V505GL, POC-V505GP, POC-V505GSP, POC-V505L, POC-V505MLP, POC-V505MNP, POC-V505MNSP, POC-V505MP, POC-V505MSP, POC-V505MZL, POC-V505P, POC-V505SP, POC-Z1GP, POC-Z1LP, POC-Z1MP, POC-Z1RGP, POC-Z1RLP, POC-Z1VGP, POC-Z1VJP, POC-Z1VLP, POC-Z1VXZLP, POC-Z1XGP, POC-Z1XJP, POC-Z1XLP, POC-Z1XMP, POC-Z1XSP, S150, S150P, S18GP, S26TP, S28TP, S36GP, S36TP, SR1, SR11K, SR17, SR17K, SR19G, SR1K, SR21, SR21K, SR5K, SR7K, SR9G, SRX41P, SRX51P, SRX51PA, SRX51PB, T17TP, T26SP, T37GP, T37SP, TR1, TR1A, TR1AP, TR2, TR2A, TR2AP1, TR2AP3, TR3, TR3A, TR3AP1, TR3AP2, TR5GP, V505A, V505AC, V505AX, V505AXP, V505B, V505BC, V505BX, V505BXP, V505D, V505DC1, V505DC11, V505DC1P2, V505DC1P7, V505DC1PC, V505D-C1PF, V505DC21, V505DC2P1, V505DX, V505DXP, V505EC, V505EC29, V505ECP1, V505ECP29, V505ECP8, V505EX, V505EXP, V505GP, V505MP, V505P, VGN-B100B, VGN-B100B01, VGN-B100B02, VGN-B100B03, VGN-B100B04, VGN-B100B07, VGN-B100B08, VGN-B100B09, VGN-B100B28, VGN-B100GP, VGN-B1VP, VGN-B1XP, VGN-B3VP, VGN-B3XP, VGN-B55C, VGN-B55G, VGN-B55L, VGN-B55S, VGN-B66GP, VGN-B66SP, VGN-B77GP, VGN-B77SP, VGN-B88C, VGN-B88GP, VGN-B88L, VGN-B99C, VGN-B99GP, VGN-G11VN/T, VGN-G11XN/B, VGN-S16GP, VGN-S16LP, VGN-S16SP, VGN-S170, VGN-S170P6, VGN-S18GP, VGN-S18LP, VGN-S18SP, VGN-S1HP, VGN-S1VP, VGN-S1XP, VGN-S25C, VGN-S260, VGN-S260P, VGN-S26C, VGN-S26GP, VGN-S26LP, VGN-S26SP, VGN-S270, VGN-S270B, VGN-S270B13, VGN-S270P, VGN-S27C, VGN-S28C/P, VGN-S28GP, VGN-S28LP, VGN-S28SP, VGN-S2HP, VGN-S2HRP, VGN-S2VP, VGN-S2XP, VGN-S2XRP, VGN-S360, VGN-S360P, VGN-S36C/B, VGN-S36C/S, VGN-S36GP/S, VGN-S36LP/S, VGN-S36SP, VGN-S38CP/B, VGN-T140P/L, VGN-T140P/LKIT1, VGN-T140P/LKIT2, VGN-T150/L, VGN-T150/LKIT2, VGN-T150P/L, VGN-T150P/LKIT1, VGN-T150P/LKIT2, VGN-T150P/T, VGN-T15C/S, VGN-T15C/T, VGN-T160P/L, VGN-T160P/LKIT1, VGN-T160P/LKIT2, VGN-T160P/S, VGN-T16LP, VGN-T16RPLS, VGN-T16SP, VGN-T170P/L, VGN-T17C/S, VGN-T17GP, VGN-T17GP/S, VGN-T17GP/T, VGN-T17LP, VGN-T17LP/T, VGN-T1XP/L, VGN-T240P/L, VGN-T250/L, VGN-T250P/L, VGN-T250P/S, VGN-T260P/L, VGN-T26C/L, VGN-T26C/T, VGN-T270P/L, VGN-T27C/L, VGN-T27GP, VGN-T27GP/L, VGN-T27GP/S, VGN-T27LP/L, VGN-T27LP/S, VGN-T27TP, VGN-T2XP/L, VGN-T2XP/S, VGN-T340P/L, VGN-T350/L, VGN-T350P/L, VGN-T350P/S, VGN-T350P/T, VGN-T360P/L, VGN-T370P/L, VGN-T37C/L, VGN-TT17GNX, VGN-TT27GDX, VGN-TT35GNB, VGN-TT35GNW, VGN-TX15C, VGN-TX16C, VGN-TX16GP/W, VGN-TX16SP/W, VGN-TX17C, VGN-TX17GP/B, VGN-TX17GP/W, VGN-TX17TP, VGN-TX1HP/W, VGN-TX1XP/B, VGN-TX1XP/L, VGN-TX27GP/B, VGN-TX27GP/T, VGN-TX27GPB, VGN-TX27GPT, VGN-TX27GPW, VGN-TX27TP, VGN-TX2HP/W, VGN-TX2XP/B, VGN-TX36GP/W, VGN-TX37, VGN-TX37GP/B, VGN-TX37GP/T, VGN-TX37GP/W, VGN-TX3HP/W, VGN-TX3XP/B, VGN-TX3XP/L, VGN-TX57GN, VGN-TX5MNV/W, VGN-TX5VN/L, VGN-TX5XN/B, VGN-TX610P/B, VGN-TX630P/B, VGN-TX650P/B, VGN-TX651P/B, VGN-TX670P/B, VGN-TX670P/W, VGN-TX690P/LKIT1, VGN-TX750P/B, VGN-TX770P/B, VGN-TX770P/T, VGN-TX770P/W, VGN-TX790P/L, VGN-TX850P/B, VGN-TXN15P/B, VGN-TXN15P/W, VGN-TXN17P/B, VGN-TXN17P/T, VGN-TXN19P/L, VGN-TXN25N/B, VGN-TXN25N/W, VGN-TXN27N/B, VGN-TXN27N/T, VGN-TXN27N/W, VGN-TXN29N/L, VGN-TZ27GNB, VGN-TZ27GNR, VGN-TZ28GNX, VGN-TZ36GN, VGN-TZ37GNB, VGN-TZ37GNN, VGN-TZ37GNP, VGN-TZ37GNR, VGN-TZ38GNX, VGN-U750P, VGN-U8G, VGN-UX17GP, VGN-UX180P, VGN-UX180PKIT1, VGN-UX1XN, VGN-UX27GN, VGN-UX280P, VGN-UX380N, VGN-UX390N, VGN-UX57GNL, VGN-X505VP, VGN-Y18C, VGN-Y18GP, VX71P, X505, X505ZPKIT, X505ZPKIT2, Z1, Z1A, Z1A1, Z1AP1, Z1AP2, Z1AP3, Z1M, Z1R5P, Z1RA, Z1RAP1, Z1RAP1KITB, Z1RAP2, Z1RAP3, Z1SP, Z1VA, Z1VAP1, Z1VAP-1KITB, Z1VAP2, Z1VAP2KITB, Z1WA, Z1WAMP1, Z1WAMP2, Z1WAMP3, Z1WAP, Z1XGP, Z1ZAP1, Z505AX, Z505AXP	✗/✗	N	✗



AC wall



DC auto



DC air

Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal		Replacement	
90W AC - AP64AU	75W AC APA02AU	90W AC	90W AC APA03AU
90W AC/DC - AP64AU			

Manufacturer	Model Name	Series	Tip	Tip	Tip
Toshiba	Libretto	U100 (PLU10A-00500W), U100 (PLU10A-00900W)	205/L104	M	✗
	Portege	3480CT (PP348E-6PU83), A600 (PPA60A-01H00G), A600 (PPA60A-03800G), A600 (PPA61A-00H005), A600 (PPA61A-00J005), M400 (PPM40A-00F00G), M400 (PPM40A-08M00G), M400 (PPM40A-1HD03D), M400 (PPM40A-1HE03D), M400 (PPM40A-3JS03Y), M400 (PPM40A-3JW03D), M405 (PPM40A-3NY03Y), M500 (PPM51A-01600D), M500 (PPM51A-01P00L), M700 (PPM70A-00W01G), M700 (PPM70A-01Q01G), M700 (PPM70A-03P01G), M700 (PPM70A-0G301G), M700 (PPM70A-0Q201G), M750 (PPM75A-007010G), M750 (PPM75A-01G010), M750 (PPM75A-01Q010), M750 (PPM75A-09U010), M750 (PPM75A-0JW010), R200 (PPR21A-00W01E), R400 (PPR40A-00H00L), R400 (PPR40A-01000L), R500 (PPR50A-00V01X), R500 (PPR50A-00V05C), R500 (PPR50A-02T01X), R500 (PPR50A-04N05C), R500 (PPR50A-04P05C), R500 (PPR50A-07Q05C), R500 (PPR50A-07R05C), R500 (PPR50A-07S05C), R500 (PPR50A-SP101X), R500 (PPR50A-SP105C), R500 (PPR50A-SSD3G), R600 (PPR61A-00300R), R600 (PPR61A-00400R), R600 (PPR61A-01L00R), R600 (PPR61A-02200R), R600 (PPR61A-02900R), R600 (PPR61A-02X00R)	205/L104	M	✗
		M600 (PPM60A-035011), M600 (PPM60A-05F01D), M600 (PPM60A-05R011), M600 (PPM60A-06T01D), M600 (PPM60A-06W01D), M600 (PPM60A-07T01D), M600 (PPM60A-09D01D), M800 (PPM80A-01900P), M800 (PPM80A-03H009), M800 (PPM81A-01U01J), M800 (PPM81A-02201J), M800 (PPM81A-04901J), M800 (PPM81A-05701S), M800 (PPM81A-05W01J), M800 (PPM81A-06L01J), M800 (PPM81A-08S01S)	206/L106	✗	P
	Satellite	A100 (PSAARA-046004), A100 (PSAARA-054007), A100 (PSAARA-055007), A100 (PSAARA-05601P), A100 (PSAARA-057007), A100 (PSAARA-058007), A100 (PSAARA-05R007), P100 (PSPA3A-05S00P)	205/L104	✗	✗
		1800 (PS181X-00XXX), 1800 (PS181X-AAAAX), A100 (PSAA8A-19Y03Q), A100 (PSAA8A-1HQ03R), A100 (PSAA9A-118038), A100 (PSAANA-04E005), M100 (PSMAAA-01M006), M100 (PSMAAA-020006), M100 (PSMAAA-026007), M110 (PSMBOA-01J00D), M110 (PSMBOA-01L00D), M40 (PSM40A-037009), M40 (PSM40A-038009), M40 (PSM40A-03K009), M40 (PSM40A-06X008), M40 (PSM40A-08L009), M40 (PSM40A-0TX008)	205/L104	M	✗
		1710/1730 (PS170A-0002C), 1730/1750 (PS173A-21KK3), 3000 (PS302A-018XK), A200 (PSAF0A-02L01C), A200 (PSAF0A-03M019), A200 (PSAF0A-04X019), A200 (PSAF0A-04Y019), A200 (PSAF0A-0CQ01C), A200 (PSAF0A-0EV019), A200 (PSAF0A-0YK01C), A200 (PSAF6A-02C01N), A200 (PSAFCA-01400J), A200 (PSAFCA-01600K), A200 (PSAFCA-01C00J), A200 (PSAFCA-01H00J), A200 (PSAFCA-01K00J), A210 (PSAFGA-05C019), A300 (PSAG8A-07V011), A300 (PSAG8A-08D011), A300 (PSAGCA-09U01N), A300 (PSAGCA-0C301N), A300 (PSAGCA-0G601Q), A300 (PSAGDA-01C00R), A300 (PSAGDA-01R014), A300D (PSAH8A-01K00H), A350 (PSAL6A-05D016), A500 (PSAM3A-03P00E), A500 (PSAM3A-03Q00E), A500 (PSAM3A-04000E), A500 (PSAM3A-04100E), A500 (PSAM3A-04200E), L300 (PSLB0A-02L022), L300 (PSLB0A-02M027), L300 (PSLB0A-08C022), L300 (PSLB0A-08D022), L300 (PSLB0A-08E022), L300 (PSLB0A-08H022), L300 (PSLB8A-01F004), L300 (PSLB8A-047004), L300 (PSLB8A-04R004), L300 (PSLB8A-04S004), L300 (PSLB8A-058004), L300 (PSLB8A-059004), L300 (PSLB8A-06X004), L300 (PSLB8A-07U004), L300 (PSLB8A-0D3004), L300 (PSLB8A-0D4004), L300 (PSLB8A-0D5004), L300 (PSLB8A-0FM004), L300 (PSLB8A-0KW004), L300 (PSLB8A-0SN004), L300 (PSLB8A-0VW004), L300 (PSLB8A-0WC004), L300 (PSLB8A-0WD004), L300D (PSLC8A-02000Y), L300D (PSLC8A-02200Y), L300D (PSLC8A-02T00Y), L300D (PSLC8A-02U00Y), L300D (PSLC8A-03U00Y), L300D (PSLC8A-03V00Y), L500 (PSLJ0A-01F013), L500 (PSLJ3A-01R015), L500 (PSLJ3A-01U015), L500 (PSLJ3A-01V015), L500 (PSLJ3A-024015), L500 (PSLJ3A-02501Y), L500D (PSLK0A-00R009), L500D (PSLK0A-00U009), L500D (PSLK0A-00W009), L550 (PSLN8A-00Y008), M200 (PSMCOA-01X00N), M200 (PSMCOA-02G00M), M200 (PSMC3A-04P008), M200 (PSMC3A-06N008), M200 (PSMC6A-03Q00S), M300 (PSMD0A-02700E), M300 (PSMD0A-04S00E), M300 (PSMD4A-023008), M300 (PSMDCA-01800C), M300 (PSMDCA-01900C), M300 (PSMDCA-01T00C), M300 (PSMDCA-03600R), M300 (PSMDCA-03700R), M300 (PSMDCA-03800R), M300 (PSMDCA-03J00R), M300 (PSMDCA-06F00R), M300 (PSMDCA-06G00R), M300 (PSMDCA-06J00S), M300 (PSMDCA-06K00R), P200 (PSPBGA-01W015), P200 (PSPBGA-01X015), P500 (PSPE8A-01R002), P500 (PSPE8A-024008), U300 (PSU30A-02Y01U), U300 (PSU30A-05302P), U300 (PSU30A-0DJ02P), U400 (PSU40A-01M001), U400 (PSU40A-01S001), U400 (PSU44A-00H00C), U400 (PSU44A-00J00C), U400 (PSU44A-02C01D), U400 (PSU44A-03S01D), U400 (PSU44A-08W01D)	206/L106	✗	P
	Satellite Pro	P100 (PSPA4A-005002), P100 (PSPA4A-016002), P100 (PSPAEA-00G00D), P100 (PSPAEA-00J00D)	205/L104	✗	✗
		A120 (PSAC0A-00D002), A120 (PSAC1A-00K005), A120 (PSAC1A-045005), A120 (PSAC1A-073004), A120 (PSAC1A-0QP01X), A120 (PSAC1A-0QV03J), A120 (PSAC1A-0R903H), A120 (PSAC1A-0VW03H), A120 (PSAC1A-0VX03J), S200 (PSSA1A-00V008), S200 (PSSA1A-0G9007), S300 (PSSB0A-06C00K), S300 (PSSB0A-06V00K)	205/L104	M	✗
		A200 (PSAF1A-001001), A200 (PSAF1A-003002), A200 (PSAF4A-001001), A200 (PSAF4A-003007), A200 (PSAF4A-008009), A200 (PSAF4A-009009), A200 (PSAF4A-00H007), A200 (PSAF4A-00J009), A200 (PSAF4A-00K009), A200 (PSAF4A-00S009), A200 (PSAF7A-003001), A210 (PSAFHA-00W008), A210 (PSAFHA-00W00L), A210 (PSAFHA-00X008), A210 (PSAFHA-00X00L), A210 (PSAFHA-01P00L), A300 (PSAG1A-003002), A300 (PSAG8A-03C011), A300 (PSAG8A-05P02D), L30 (PSL30A-00100E), L300 (PSLB1A-01L019), L300 (PSLB1A-01L019), L300 (PSLB1A-01N008), L300 (PSLB1A-02C01E), L300 (PSLB1A-02D008), L300 (PSLB1A-02R01E), L300 (PSLB1A-02S008), L300 (PSLB9A-00L002), L300 (PSLB9A-013001), L300 (PSLB9A-01G002), L300 (PSLB9A-02H002), L300 (PSLB9A-02K002), L300 (PSLB9A-02L001), L300 (PSLB9A-03T002), L300 (PSLB9A-058001), L300 (PSLB9A-05U002), L300 (PSLB9A-05W002), M200 (PSMC4A-00C001), M200 (PSMC4A-01N00C), M300 (PSMD1A-005004), M300 (PSMD9A-003002), M300 (PSMD9A-004002), M300 (PSMD9A-007002), P300 (PSPCDA-01N00D), P300 (PSPCDA-01P00D)	206/L106	✗	P



AC wall



DC auto



DC air

Universal adaptors are available in AC & AC/DC versions to provide power wherever it's needed. They will work with more than 90% of laptops in the market and can be used with most laptops via interchangeable tips that adjust the voltage & current. **Replacement AC adaptors** are limited to laptop models that use 15/16V & 19/20V to suit most common brands & models –they are ideal as replacement or additional AC adaptors, but may not work with your next laptop.

Universal	Replacement	
90W AC - APA64AU 90W AC/DC - APB64U	75W AC APA02AU	90W AC APA03AU

Manufacturer	Model Name	Series	Tip	Tip	Tip
Toshiba	Tecra	A6 (PTA63A-002002), A7 (PTA71A-012003), A7 (PTA71A-0DU003), A7 (PTA71A-0DW003), A7 (PTA71A-1EU003), A8 (PTA83A-0HV041)	205/L104	✘	✘
		A10 (PTSB0A-002001), A10 (PTSB0A-006001), A10 (PTSB0A-00E001), A10 (PTSB0A-020001), A10 (PTSB0A-02D001), A10 (PTSB0A-03E001), A10 (PTSB0A-03G001), A10 (PTSB0A-04L001), A6 (PTA61A-093005), A8 (PTA83A-042012), A8 (PTA83A-04F012), A8 (PTA83A-04G012), A8 (PTA83A-054012), A8 (PTA83A-056012), A8 (PTA83A-0HU041), A8 (PTA83A-0HV041), A8 (PTA83A-0HW041), A8 (PTA83A-0K5041), A9 (PTS52A-00T00F), A9 (PTS52A-00U00F), A9 (PTS52A-00V00F), A9 (PTS52A-023017), A9 (PTS52A-0CT017), A9 (PTS52A-0CU03F), A9 (PTS52A-0CV03F), A9 (PTS52A-0CW03F), A9 (PTS52A-0EV017), A9 (PTS52A-0EW03F), A9 (PTS52A-0EX03F), A9 (PTS52A-0EY03F), A9 (PTS52A-0GF03F), M10 (PTMB0A-00M001), M10 (PTMB3A-00L004), M10 (PTMB3A-00M004), M10 (PTMB3A-00N004), M10 (PTMB3A-01X001), M10 (PTMB3A-04L001), M10 (PTMB3A-05C004), M10 (PTMB3A-05E004), M10 (PTMB3A-0D3004), M10 (PTMB3A-0G0004), M10 (PTMB3A-0HK004), M5 (PTM51A-0EG007), M5 (PTM51A-0EJ007), M5 (PTM51A-0RL05P), M5 (PTM51A-0RM05P), M5 (PTM51A-0RW05P), M5 (PTM51A-1FQ07P), M7 (PTM71A-01101H), M9 (PTM90A-01V00K), M9 (PTM90A-08P03H), M9 (PTM90A-0C603H), M9 (PTM90A-0CL03H), M9 (PTM91A-035002), M9 (PTM91A-036002), M9 (PTM91A-037002), M9 (PTM91A-05504L), M9 (PTM91A-0E104L), M9 (PTM91A-0EY04L), M9 (PTM91A-0MF04L), M9 (PTM91A-0MG04L), M9 (PTM91A-0T304L), M9 (PTM91A-0U204L), M9 (PTM91A-0U204L), P (PTS40A-02100V), P (PTS40A-02800V), P10 (PTSB3A-001001), P10 (PTSB3A-00S001), P10 (PTSB3A-05Q001), P10 (PTSB3A-05R001), P10 (PTSB3A-07U016), P10 (PTSB3A-0GE001), P10 (PTSB3A-0GF001), P10 (PTSB3A-0HE001), P5 (PTS53A-007006), P5 (PTS53A-009006), P5 (PTS53A-01G006), P5 (PTS53A-02F01D), P5 (PTS53A-05H03X), P5 (PTS53A-05Y01D), P5 (PTS53A-05Y03X), P5 (PTS53A-06003X), P5 (PTS53A-0FR03X), P5 (PTS53A-0FS03X), P5 (PTS53A-0FT03X), R10 (PTRB3A-001002), R10 (PTRB3A-00T002), R10 (PTRB3A-00U002), S3 (PTS30A-094008), S3 (PTS30A-0CG008)	205/L104	M	✘
	Toshiba Netbook	NB100 (PLL10A-00K02H), NB100 (PLL10A-01C02H), NB100 (PLL10A-01E02H), NB200 (PLL20A-002001), NB200 (PLL20A-00P001), NB200 (PLL20A-00Q001), NB200 (PLL25A-009002), NB200 (PLL25A-00C002), NB200 (PLL25A-00D002), NB200 (PLL25A-00K002)	206/L106	✘	P
WinBook	WinBook	J1, N, Si, Si2, X1, X2, X4, XL, XLi, XP, Z	206/L106	✘	P